# Alarm Help    - MV SERIES -

**QUASER**
*we cut faster*

| ALARM ADDRESS | A0.2 | ALARM NO. | 1002 |
|---|---|---|---|
| **ALARM TEXT** | Z LIMIT EMG. STOP. -> M.RST. | | |
| **Related Signal** | Input: X8.2 (MV154/154APC/MV204) , X8.7(184C)。 | | |
| **CAUSE** | Same as AL1000 situation。<br><br>Z Axis Limit Switch  | | |
| **ACTION** | Same as AL1000 operating procedure。 | | |