Alarm Help - MV SERIES -



ALARM ADDRESS	A11.1	ALARM NO.	1173
ALARM TEXT	PRESS SRV KEY -> SPDL ORIENT.		
Related Signal			
CAUSE	When ATC cycle was interrupted. This is a prompt for operator •		
ACTION	Press service button the Spindle will perform orientation •		