Alarm Help - MV SERIES -



ALARM ADDRESS	A17.0	ALARM NO.	2032
	!!!ATTENTION!!!		
OP. MESSAGE	APC INTO SRV-MODE,NO INTERLOCK ACTION DAMAGE OF MECHINE POSSIBLE.		
	CLEAR THIS MODE BY "RESET" KEY !!		
Related Signal			
CAUSE	APC service has be turn on •		
	Operator must pay attention to operate machine.		
ACTION	Cancel this function by press reset button on FANUC panel •		