## Alarm Help - MV SERIES -



ALARM ADDRESS	A12.5	ALARM NO.	1185
ALARM TEXT	NOW => ATC-ARM AT BOTTOM		
Related Signal	Input: X0.4 ,X0.5 , X0.6 , X0.7 (MV154/154APC/MV204) ,		
CAUSE	In ATC service mode, This is a prompt for operator •		
ACTION			