Alarm Help - MV SERIES -



ALARM ADDRESS	A9.1		ALARM NO.	1157
ALARM TEXT	SCREW AUGER MOTOR OL.			
Related Signal	Input: X7.4 (MV154/154APC/MV204) , X9.6 (184C) 。 Output: Y0.4 ,Y0.5 (MV154/154APC/MV204) , Y4.4 ,Y4.5 (184C)。			
CAUSE	Screw Auger break		21h CHIP AU 21 RAUGER OV	CW6 JGER CW Q6 21Q7 LAUGER OVERLOAD RELAY PRIMATE D PRI
ACTION	Turn on the breaker at cabinet as attached label indicated. • Cancel alarm by reset button on FANUC panel •			