Alarm Help - MV SERIES -



ALARM ADDRESS	A11.0	ALARM NO.	1172
ALARM TEXT	PRESS SRV KEY -> ARM CCW TO 0D.		
Related Signal			
CAUSE	When ATC cycle was interrupted. This is a prompt for operator •		
ACTION	Press service button the ARM will perform CCW to 0 degree •		