Alarm Help - MV SERIES -



| ALARM ADDRESS | A23.7 | ALARM NO. | 2087 |
|----------------|--|-----------|------|
| OP. MESSAGE | COOLANT TANK LEVEL TOO LOW | | |
| Related Signal | Input: X1.4 (MV154/154APC/MV204) , X10.1 (184C) 。 | | |
| CAUSE | CAUSE CAUSE | | |
| | Coolant level dete | ector • | |
| ACTION | 1. Fill up coolant into coolant tank , as mafked level . | | |
| | 2. Cancel message by message reset button | | |