Alarm Help - MV SERIES -



ALARM ADDRESS	A15.3	ALARM NO.	2019
OP. MESSAGE	CONDITION OF MAN. TOOL UNCLAMP:		
	1.FRONT DOOR MUST BE OPEN.		
	2.MANUAL MODE.		
	3.SPINDLE STOP.		
Related Signal	Input: X2.2 (MV154/154APC/MV204) , X8.0 (184C) • Spindle tool unclamp button •		
CAUSE	One of the conditions of perform spindle tool unclamp by manual is not match •		
ACTION	Follow op. message to correct each condition, then try again •		