## Alarm Help - MV SERIES -



ALARM ADDRESS	A6.0	ALARM NO.	1132
ALARM TEXT	THE TOOL IS NOT REGISTERED.		
Related Signal			
CAUSE	Tool NO. can't be called on data table as T command on programming •		
	1.Check data table D102 -> D148, D501 -> D524 •		
	2.Pocket up/down signal(X5.1/X5.2) disappear during tool change.		
	3.Tool clamp/unclamp signal (Y3.0/Y3.1) disappear during tool change.		