Alarm Help - MV SERIES -



ALARM ADDRESS	A6.5	ALARM NO.	1137
ALARM TEXT	ARM1 & 2 DATA ERR. CHK D6 & D8.		
Related Signal			
CAUSE	ARM at 0 Degree, But data table ARM1(D6) & ARM2(D8) not equal 0 •		
ACTION	Modify data table manually •		
	If ARM at 0 Degree : set ARM1 tool NO. (D6) to 0 & ARM1 tool type (D53) to 0 •		
	set ARM2 tool NO. (D8) to 0 & ARM2 tool type (D54) to 0 •		
	Press RESET key to clear alarm •		