Alarm Help - MV SERIES -



ALARM ADDRESS	A23.0	ALARM NO.	2080
OP. MESSAGE	MACHINE READY STEP:		
	1.RELEASE ALL OF EMG. STOP.		
	2.PRESS START-UP PB. MORE THEN 2 SEC.		
Related Signal	Input: X8.3 (OP. panel EMG.), X6.7 (MAG. Ctrl panel EMG.)		
	(MV154/154APC/MV204) , X8.3 (OP. panel EMG.), (184C) 。		
CAUSE	One of the EMG. Stop button has been pushed, and operator push machine		
	4		
	startup button -		
ACTION	1. Release all of EMG. Stop button •		
		(1)	
	2. press machine startup button	more ti	hen 2 seconds •