## Alarm Help - MV SERIES -



ALARM ADDRESS	A26.0	ALARM NO.	1208
OP. MESSAGE	VISE A/CUTTING AREA PRESSURE ALM(0D).		
Related Signal	Input: X5.5 (MV154) •		
CAUSE	Hydraulic pressure too low for vise system		
	1.check hydraulic pressure.		
ACTION	2.adjust pressure switch.		
	3.pressure switch damaged		