## Alarm Help - MV SERIES -



| ALARM ADDRESS  | A4.0                                       | ALARM NO. | 1116 |
|----------------|--|-----------|------|
| ALARM TEXT     | ATC FRONT DOOR OPEN & CLS BOTH ON.         |           |      |
| Related Signal | Input: X4.0 , X4.1 (MV154/154APC/MV204) 。  |           |      |
| CAUSE          | ATC front door open & close sensor both on |           |      |
| ACTION         | Check sensor is damaged?                   |           |      |