## Alarm Help - MV SERIES -



|                |   |            | we cut faster  |
|----------------|---|------------|--|
| ALARM ADDRESS  | A9.2  | ALARM NO.  | 1158   |
| ALARM TEXT     | CHIP CONVEYOR MOTOR O.L.  |            |  |
| Polated Signal | Input: X7.3 (MV154/154APC/MV204) , X9.6 (184C) •  |            |  |
| Related Signal | Output: Y0.3 (MV154/154APC/MV204) , Y4.2 (184C) •   |            |  |
| CAUSE          | Chip conveyor motor   | CHIP CONV. | CONV. CW IQ4 OVERLOAD RELAY  PRINTING THE PRINTING THE TRANSPORT IN THE PRINTING TH |
| ACTION         | Turn on the breaker at cabinet as attached label indicated. •  Cancel alarm by reset button  on FANUC panel • |            |  |