Alarm Help - MV SERIES -



ALARM ADDRESS	A16.1	ALARM NO.	2025
	CONDITION OF SPDL RST:		
	1.ALL OF AXES FEED HOLD.		
	2.NOT IN RIGID TAPPING MODE.		
Related Signal			
CAUSE	During axes moving or machine in rigid tapping cycle and operator perform		
	spindle reset function •		
ACTION	1. Press feed hold button to stop all of axes •		
	O Proce food bold bottom	, ,	
	2. Press feed hold button	→ana press spir	ndle stop button at same
	time ∘		