Alarm Help - MV SERIES -



ALARM ADDRESS	A15.4	ALARM NO.	2020
OP. MESSAGE	ATC CYCLE INTO SBK. MODE.		
	PRESS C-START PB> STEP BY STEP.		
Related Signal			
CAUSE	When operator press feed hold button and single block button the ATC cycle will into single block mode and also this message appeared. Press cycle start button to perform ATC cycle step by step		
ACTION	Cancel this function by cancel single block mode -		