Alarm Help - MV SERIES -



ALARM ADDRESS	A11.3	ALARM NO.	1175
ALARM TEXT	PRESS SRV KEY -> SPDL TOOL UNCLAMP.		
Related Signal			
CAUSE	When ATC cycle was interrupted. This is a prompt for operator •		
ACTION	Press service button the Spindle will perform tool unclamp •		