Alarm Help - MV SERIES -



ALARM ADDRESS	A6.2	ALARM NO.	1134	
ALARM TEXT	CLR TASK BY "RST+FEED HD"=>2SEC.			
Related Signal				
CAUSE	During ATC cycle interrupted, operator want to into service mode but the ATC task still exist •			
ACTION	This is a prompt for operator • ATC task must be clear before in		to,	//
	Method of ATC task clear : Press great then 2 seconds •	reed hold butto	on + RST	