


## Module: Solidworks CAM Standard-Milling

### Topic 6: Automatic Recognition Feature Setup 5- Generate Operation Plan

#### 6.0 Generate Operation Plan


Once our features have been defined, we may generate our operation plan. Click **Generate Operation Plan** in the CAM command manager or pick your right-mouse-button on Mill Part Set-up1 and select Generate Operation Plan.




Now our features will be converted to machining operations using our defined strategies. If you see a yellow flag beside one of your operations a tool has been selected that does not exist in your tool crib. Pick your right-mouse-button in the operation and select What's Wrong. Clearing this error will automatically add the tool to your tool crib.

## Module: Solidworks CAM Standard-Milling

### Topic 6: Automatic Recognition Feature Setup 5- Generate Operation Plan



We may manually alter any operation by double clicking on it or pick your right-mouse-button and select Edit Definition.



Here we may alter our tool, speed/feed rates, cutting and NC parameters manually.