UECS1013 Introduction to Computer Organisation and Architecture

2014/May/Lecture 1

1

INTRODUCTION

- History of Computers
- What is a Computer?
 - Multi-level Computer Units
 - Types of Computer
- Functional Units
 - Memory
 - Input and Output Unit
 - CPU
 - Bus
- Basic Operational Concepts

What is a Computer?

Туре	Price (\$)	Example application
Disposable computer	1	Greeting cards
Embedded computer	10	Watches, cars, appliances
Game computer	100	Home video games
Personal computer	1K	Desktop or portable computer
Server	10K	Network server
Collection of Workstations	100K	Departmental minisupercomputer
Mainframe	1M	Batch data processing in a bank
Supercomputer	10M	Long range weather prediction

In general, a computer is a machine that can solve problems for people by carrying out instructions given to it.

3

History of Computers

Mechanical Computers

- Abacus invented in Babylonia in 3000BC
- Adding machine by Blaise Pascal (1642)
- IBM first electromechanical computer (using relays) designed by Howard Aiken (1937) was based on punched cards. It was used to calculate tables of mathematical functions.
- Holes on punched card were mechanically sensed and used to control the automatic sequencing of a list of calculations



ı

History of Computers

- 1st Generation Computers (1940s to early 1950s) based on vacuum tubes technology.
 - 1943 ENIAC: first fully electronic computer, designed by John Mauchly (100 to 1000 times faster than mechanical computers)
 - 1946 EDVAC: first stored program computers, designed by John von Neumann
 - Magnetic core memories were developed
 - Magnetic tape storage devices were developed
 - Programmes were written in assembly language



- 2nd Generation Computers (late 50s to early 60s) based on transistors (solid state) technology.
 - more reliable, less expensive, low heat dissipation
 - ❖ IBM 7000 series, DEC PDP-1.
 - Magnetic core memories were prominent.
 - ❖ Magnetic disk storage devices were developed
 - High-level languages such as Fortran were developed. Compilers were used to translate high-level languages to assembly languages

History of Computers

- 3rd Generation Computers (late 60s to early 80s) integrated circuits (IC).
 - Texas Instrument and Fairchild Semiconductor developed the capability to fabricate many transistor on a single silicon chip, called integrated circuits (IC)




- IBM 360 series, DEC PDP-8
- ❖ Many transistors packed into single container → low prices, high packing density
- Introduction to pipelining (multiple instructions at the same time), cache (memory appear faster) and virtual memory (memory appears bigger)

History of Computers

- 4th Generation Computers Very Large Scale Integration (VLSI)
 - ❖ Advances in processing/manufacturing technology → tens of thousands of transistors could be placed on a single chip → small size, low-cost, large memory, ultra-fast PCs to supercomputers




- Driving force: Intel, National Semiconductor, Motorola, Texas Instrument and Advanced Micro Devices
- Embedded computer systems and portable notebooks become widespread
- Supercomputers and grid computers emerges as the upper end computing systems for weather forecasting, scientific and engineering computations and simulations
- 5th Generation Computers (Parallel Computing)
 - Multi-core processors
 - Massively parallel, Cloud/Grid Computing, etc.



What is a Computer?

- Computer = Hardware + Software.
 - Hardware: physical components for computation/processing; should be simple, fast, reliable.
 - *Software*: set of instructions to perform tasks to specifications; should be flexible, user-friendly, sophisticated.
- Computers are information processors



Data Units:

- The hardware components of a computer system represent information as 0 (as 0V) or 1 (as either 1.8V or 3.3V or 5V).
- Therefore, data must be represented using binary digits consisting of only 0 and 1.

1 bit (binary digit): one of two values (0 or 1)

1 byte: 8-bits

1 word: 1, 2, or 4 bytes, or more (depends on ALU)

.

Multi-level Architecture


Applications High level languages Assembly Language Machine Language Operating System Instruction Set Architecture Micro-architecture Digital Logic

Software

- High-level abstraction
- Closer to a human understanding of the problem
- Easier to program. Do not require much understanding of the computer hardware
- Low-level implementation
- Closer to how the machine solves the problem.
- Difficult to program. Requires in-depth knowledge of the computer hardware

Actual physical implementation


Multi-level Architecture



- There is a large gap between what is convenient for people (the code can be understood and written easily by a human) and what is convenient for computers (code is in binary form).
- Abstraction implies that any layer can hide the details of the layers below it from the layers above it.
- 3. For example, Instruction Set Architecture (ISA) is the abstraction layer between hardware and low level software layer.
- 4. Programmers are only interested in the top level but people interested in understanding how a computer really works must study all the levels.

1

High Level Languages



- 1. For a *software developer* to develop *applications* such as a library catalogue system, Office, Winzip, game, etc.
- 2. Examples of high level languages:

C++, Matlab, Java, Java Script, etc.

- High level languages are much easier for human to understand than assembly language program and are designed to be used by application programmers with problems to solve.
- Example C++ code for C= A + B int A, B, C; // variable declaration

C = A + B; // add operation

5. Programs are generally translated to lower levels by *compilers*.

Assembly Language Level

- 1. For *computer engineers* to develop the software to control the operations of a system, e.g., walkie talkie, routers, etc.
- 2. A symbolic form for the underlying language. The language is specific to the hardware. Example: ARM/MIPS
- 3. Assembly language (low level language) programs are usually easier to create than machine language program but still requires an in-depth knowledge of the computer architecture (hardware resources).
- 4. Example code for C = A + B

LDR R0, A ; Load A into register R0 LDR R1, B ; Load B into register R1

ADD R2, R1, R0 ; Add R0 and R1 and save result to R2

STR RO, C ; Save the result into C

5. An *assembler* translates programs written in an assembly language into a sequence of machine instructions.


13

Machine Language Level

- 1. Native codes for the machine, consisting of strings of 1's and 0's and stored as binary numbers.
- 2. The very lowest possible level at which you can program a computer. Difficult for a human programmer to program but useful for debugging purposes.
- 3. Specific to the hardware: the machine language code assembled for Intel x86 system cannot run on a ARM platform
- 4. Example machine to add two variables (C=A+B)

<u>C++</u>	Assembly	Machine Language
int A, B, C;		
	LDR R1, A	E59F1010
C = A+B;	LDR RO, B	E59F0008
	ADD R2, R1, R0	E0812000
	STR R5, C	E58F5008

14



Applications

High level languages

Assembly Language

Machine Language

Operating System

Instruction Set Architecture

Digital Logic

Micro-architecture

Operating System Level

- A series of programs serves as a kind of protective shell or buffer to serve users and application programs from the complexities of the hardware.
 Operating system is a resource manager:
 - · Manages all resources
 - Decides between conflicting requests for efficient and fair resource usage (memory or CPU time)
 - Control shared resources so that different users are given fair share
 - 3. Operating system is a control program
 - Controls execution of programs to prevent errors and improper use of the computer
 - Protect the system from incorrect or malicious program and users

1.5

Instruction Set Level

Applications

High level languages

Assembly Language

Machine Language

Operating System

Instruction Set
Architecture

Micro-architecture

Digital Logic

Applications

High level languages

Assembly Language

Machine Language

Operating System

Instruction Set

Architecture

Digital Logic

Micro-architecture

- The set of all *instructions* that is visible and available to a system-level programmer to control the operations of a PC.
- 2. The instructions are specific for a particular hardware. Example: The instruction set for ARM is different from MC68000 system.
- 3. The *abstraction layer* between the actual hardware and the low-level software.
- 4. May be carried out interpretively either by the microprogram or hardware at the microarchitecture level.
- 5. Example instructions:

ADD Rx, Ry LDR, Rx, Ry

Microarchitecture Level

- 1. At this level, registers are connected to the ALU to form a data path, over which the data flow.
- 2. The operation of the data path (from registers to ALU) is controlled directly by a program called a microprogram or directly by hardware.
- 3. A microprogram is an interpreter for the instructions at ISA:

e.g., ADD

Applications

High level languages

Assembly Language

Machine Language


Operating System

Instruction Set Architecture

Aicro-architecture

Digital Logic

- a. fetch instruction
- b. locate operands and bring into registers
- c. compute sum by the ALU



Computer Types

Embedded Computers

- Integrated into a larger system to automatically monitor and control a physical process.
- Used for specific purpose rather than for general tasks.
- Typical applications: industrial and home automation, appliances, telecommunication products and vehicles.
- Examples:







Washing machines

ABS Braking System

19

Computer Types

Personal Computers

- Unlike Embedded Computers, personal computers are generalpurpose – could be used to perform a variety of tasks
- Used at different settings (homes, educational institution, business and engineering departments) and can be installed with a variety of application

Servers and Enterprise Systems

- Large computers that are shared by large number of users
- Each user can be a personal computer over a public or private network.
- ❖ Example: database & information processing for government

Computer Types

Supercomputer

- Used for highly demanding computations, e.g., weather forecasting, engineering design and simultation, scientific high costs.
- Offering the highest performance
- Most expensive and physically the largest

Year	Supercomputer	Peak speed (Rmax)	Location	
2008	2000		L Al 116A	
2008	IBM Roadrunner	1.105 PFLOPS	Los Alamos, USA	
2009	Cray Jaguar	1.759 PFLOPS	Oak Ridge, USA	
2010	<u>Tianhe-I</u> A	2.566 PFLOPS	<u>Tianjin</u> , China	
2011	Fujitsu K computer	10.51 PFLOPS	Kobe, Japan	
2012	IBM Sequoia	16.32 PFLOPS	<u>Livermore</u> , USA	
2012	<u>Cray Titan</u>	17.59 PFLOPS	Oak Ridge, USA	
2013	NUDT Tianhe-2	33.86 PFLOPS	Guangzhou, China	

Source: Wikipedia

2

Computer Types

Grid Computing

- More cost effective than super computer
- Links a large number of disparate personal computers and disk storage units in a physically distributed high-speed network (grid)
- Grid computing relies on software (middleware) to divides/directs pieces of a program to a number of different computers.
- Allows remote access to computing resources
- Computing power is aggregated but with communication overhead

Cloud Computing

- Built upon the foundation of Grid Computing
- Further offers on-demand resource provisioning. Allows companies immediate access to high computational power without having into developing new infrastructure by outsourcing

Computer Types

Cloud Computing (...cont)

- Providers can provide cloud services as 3 different services
- a) Infrastucture as a Service (laaS)
 - Cloud provider supplies the physical or virtual machines, raw storage, load balancers and network from their large pool of computing equipments installed in data centers.
 - Customer install their operating system images & software on the machines before deploying their application.

b) Platform as a Service (PaaS)

- Cloud provider supplies the platform (operating system, programming language environment and web server)
- Customer develops software solutions on the cloud platform (do not need to invest in infrastructure to start)

c) Software as a Service (SaaS)

- Cloud provides and installs the application software
- Customer to run the computational expensive application in the cloud network to enjoy the desired high performance

Functional Units Arithmetic Logic Unit (ALU) Control Unit (CU) Registers Central Processing Unit (CPU)

CPU Components:

- CPU: performs mathematical & logical operations, controls operations of a computer).
- Memory: stores programs and intermediate data.
- Input Devices: accept data from outside world.
- Output Devices: presents data to the outside world.
- **Bus:** communication between the components


An analogy with Human Information Processors:

- CPU brain's reasoning powers
- Memory brain's memory
- Input Devices eyes, ears, sensory sub-system
- Output Devices mouth, hands, facial and body expressions
- ❖ Bus nerves

Memory

Primary Memory (Main Memory)

- · All programs and their data must be hold in this memory while they are being executed
- Constructed from semiconductor bit cells, each capable of storing one bit.
- Memory are typically accessed in groups of fixed size called words. The number of bits in each word is called word length and is typically 16, 32 or 64 bits.
- Primary memory is typically RAM
- Memory access time: time to access one word.
- Random-access memory (RAM): memory where the access time is short and fixed regardless of its location



Cache

- · An adjunct to the main memory, fabricated on the processor chip
- Much smaller and faster than the main memory
- · Holds only part of the program and data currently being executed by the processor

25


Memory

Register

- · Fastest memory in the system
- Used to store the data that is currently being executed

Secondary Storage

- Primary memory is expensive and is volatile (does not retain the content when power is turned off)
- Secondary storage is a non-volatile memory that is used to store large amounts of data and programs. Example: magnetic disks, optical disks, flash memory devices
- A magnetic disk can store 500 or more Gigabytes



Fast, expensive (small numbers), volatile




Slow, cheap (large numbers), non-volatile

Input and Output Unit

Input Units

- Computer accepts coded information through input units
- Provides human-computer interaction: keyboards, mouse, touch screen
- Provides digital communication facilities such as Internet to allow computers to communicate
- Provides data transfer for secondary storage devices: hard disk (file transfer or load a program into memory), microphone (capture, audio input to be sampled and converted into digital codes for storage)




Output Units

- Counterpart of the input units.
 Used to send processed results to the outside world
- Example: printer, monitor, graphic display, etc.
- Some units performs both functions of input and output, e.g., touch screen, network card, etc.

27

Central Processing Unit (CPU)


 Execute programs (a set of instructions to accomplish a certain task) that are stored in the main memory by fetching and then executing them one after another.



- Arithmetic Logical Unit (ALU)
 - Performs *arithmetic* and *logical* operations such as addition, subtraction, multiplication, comparison of numbers, etc.
 - These operations is initiated by bringing the required operands into the processor, where the operation is performed by the ALU
 - For example, when adding two numbers in the memory, these two numbers are first be brought into the processor before addition is carried out by ALU.
 - The sum may then be stored in the memory or retained in the CPU (register) for immediate use.
- Registers are <u>high speed</u> memory used to temporarily store the variables in an instruction currently executed by the CPU.

Central Processing Unit (CPU)

 Execute programs (a set of instructions to accomplish a certain task) that are stored in the main memory by fetching and then executing them one after another.




- Control Unit co-ordinates the operations between different units
 - Control circuits are responsible for generating the timing signals and control signals that govern a particular computer operation (e.g. addition, or data transfer)
 - *Timing signals* synchronizes the computer operation so that all steps are executed in the right sequence.
 - Control signals controls the data transfer. For example, to perform REG1
 + REG2, the first and the second input to the ALU is directed from REG1 and REG2, respectively and not other registers
 - In reality, a control unit is not a well-defined, physical structure but is rather physically distributed throughout the computer.

29

Bus

- Buses are communication links allowing data, instructions and memory addresses to be referenced between different components (CPU, main memory and I/O devices) in a computer system.
- A bus is a group of lines such that a word of data can be transferred (one bit per line) at a time.
- Bus arbiter (not shown in the diagram) is controller that decides which requesting device is granted access to the bus when multiple devices share the same bus.



Basic Operational Concepts

- An instruction specifies an operation and its data operands. For example, the instruction ADD R4, R3, R2 for the ARMS processor adds the content of R3 and R2 and stores the result in R4.
- The basic instructions type are:

Load
Read a data operand from memory or an input device into the CPU
Store
Write a data operand from a CPU register to memory or an output device
Operate
Perform an arithmetic or logic operation on data operands in CPU registers
Flow
Control the execution flow (if-else and while statements)

- A program is a sequence of instructions, executed one after another, to perform a particular task.
- All programs and its data needs to be stored in the main memory before it can be executed.

Basic Operational Concepts

Sample program for the ARM processor:


Write a program to perform the following operation:

$$C = A + B$$

- A, B, and C, are labels representing memory word addresses;
- · Ri are processor registers

```
LDR R2, A ; Load A into CPU register 2
LDR R3, B ; Load B into CPU register 3
ADD R4, R2, R3 ; Add register 3 and 2 and save into register 4
STR R4, C ; Store result into memory location C
```

Basic Operational Concepts



The basic operation of a Computer:

(1) Load:

Program (*instruction+data*) is loaded from storage unit into memory.

(2) Fetch

4

By default, CPU fetches the **instructions** (of the program) from the memory <u>line by line</u> sequentially. The control unit decodes the instruction to identify the *instruction* (load) with its *field* (A and R2)

(3) Execute:

Each instruction line is executed by CPU.

33

NUMBER SYSTEM

- Positional Notation Number System
 - Decimal Number (Base 10)
 - Binary (Base 2)
 - Octal (Base 8)
 - Hexadecimal (Base 16)
 - Conversion from other Bases to Base 10
 - Range of a Number System (Integers)
 - Fractions

Positional Notation Number System

- Number System: a mathematical notation used to represent numbers of a given set by using symbols in a consistent manner.
- Position Independent Number Systems: a number system where the number of digits representing a number does not reflect the true value of the number.

Example: Roman: I, II, III, IV, V,

 Positional Notation Number Systems defines a finite set of numeric symbols/digits and then use multiple digits to represent numbers that are larger than the number of symbols.

Example: Decimal: 1, 2, 3, 4, ..., 10, 11,, 99, 100, ...

- For these systems, the Base of a number system represents the number of digits that are defined:
 - Binary (Base 2): 0, 1
 - Octal (Base 8): 0, 1, 2, 3, 4, 5, 6, 7
 - Decimal (Base 10): 0, 1, 2, 3, 4, 5, 6, 7, 8, 9
 - Hexadecimal (base 16): 0, 1, 2, 3, 4, 5, 7, 8, 9, A, B, C, D, E, F

Positional Notation Number System

Why do we focus on binary, octal, decimal and hexadecimal number system whereas we can also have Base 3, Base 5, Base 6, ...?

- Human are familiar with Base 10 (Decimal) number system
 - a. Base 10 uses 10 digits (0, 1, 2, ...9) to represent numbers
 - b. Origin: counting on the fingers
 - c. "Digit" from the Latin word digitus meaning "finger"
- A computer "has only two fingers" and therefore it operates in the Base 2 (Binary) number system.
 - a. The input to the logic gates contains only two possible values. The elementary storage units inside computer are electronic switches. Each switch holds one of two states: *on* (1) or *off* (0).
 - b. Base 2 uses a **bit** (two *bi*nary digi*t*), 0 or 1, to represent numbers


OFF



ON

Positional Notation Number System

- To represent a value larger than the total number of digits in a number system, we can use **multiple** digits.
 - For example, the number twelve cannot be represented using a single decimal digit (ten valid symbols only), and we have to use two digits (12₁₀)
 - For example, 1 switch in a *binary* system can represent 2 values and two switches can represent 4 values.



- In this system, the position of the digits is assigned a certain weight based on the base value.
 - **Binary** (Base 2): weights are in the powers-of-2.
 - Octal (Base 8): weights are in the powers-of-8.
 - Decimal (Base 10): weights are in the powers of 10
 - **Hexadecimal** (base 16): weights are in the powers-of-16.

37

Positional Notation Number System

Notations:

 To differentiate between the different bases, the subscript value following the number itself denotes the base that the number is being represented. For example

> 10100₂ (in base 2), 263₇ (in base 7) 129₁₀ (in base 10), 8AE7₁₆ (in base 16)

- The largest digit in a number must not be bigger than the base.
 For example, the largest digit in 10100₂ is 1 and the largest digit in 523₆ is 5.
- The same set of digits in different number system represents different numbers. For example:

$$111_2 \neq 111_8 \neq 111_{10} \neq 111_{16}$$

 $1101111_2 \neq 157_8 = 111_{10} = 6F_{16}$

A number is not followed by any subscript, the default base (Base 10) is assumed. For example, 124 = 124₁₀.

Decimal (Base 10 Integers)

• An integer in decimal system is a sequence of digits:

$$A = a_{n-1} \dots a_0$$

For example:

$$A = 234$$
, $a_2=2$, $a_1=3$, $a_0=4$ (n = 3, zero-indexed)

• Each digit is one of the followings:

• The value (in base 10) represented by the above sequence is

$$\sum_{i=0}^{n-1} a_i \times 10^i$$

Decimal (Base 10 Integers)

• Examples

$$527_{10} = 5 \times 10^2 + 2 \times 10^1 + 7 \times 10^0$$

i	2	1	0	
Weight	10 ²	10¹	10º	
	100	10	1	
Value x	Value x 5 x 100		7 x1	
Weight				
Sum	500	20	7	

$$527_{10} = 5 \times 10^2 + 2 \times 10^1 + 7 \times 10^0$$
 $43_{10} = 4 \times 10^1 + 3 \times 10^0$

10		
i	1	0
Weight	10¹	10 ⁰
	10	1
Value x Weight	4 x 10	3 x1
Sum	40	3

Binary (Base 2 Integers)

- A number in binary system is a sequence of bits, possibly followed by a binary point and then a sequence of bits.
- The actual value (in Base 10) represented by the binary number is:

$$A = \sum_{i=0}^{n-1} a_i \times 2^i$$

1101 0110₂ = 128 + 64 + 16 + 4 + 2 = 214₁₀

i	7	6	5	4	3	2	1	0
Weight	2 ⁷	2 ⁶	2 ⁵	2 ⁴	2 ³	2 ²	2 ¹	2 ⁰
	128	64	32	16	8	4	2	1
Value x Weight	1x128	1x64	0x32	1x16	0x8	1x4	1x2	0x1
Sum for Base 10	128	64	0	16	0	4	2	0
								41

Binary (Base 2 Integers)

• In computer terminology,

1 Kilo (K) =
$$2^{10}$$

1 Mega (M)
$$=2^{20}$$

1 Giga (G)
$$=2^{30}$$

1 Tera (T)
$$=2^{40}$$

Examples:

4KB =
$$2^2 \times 2^{10} = 2^{12} = 4,096$$
 bytes

16MB =
$$2^4 \times 2^{20} = 2^{24} = 16,777,216$$
 bytes

$$2TB$$
 = $2^1 \times 2^{40} = 2^{41} = 2,199,023,255,552$ bytes

Octal (Base 8 Integers)

1. The possible digits in an octal number are:

0, 1, 2, 3, 4, 5, 6, 7

2. The actual value (in Base 10) represented by the octal digit sequence $A_{n-1}...A_1A_0$ is:

$$\sum_{i=0}^{n-1} a_i \times 8^i$$

Position	2	1	0
Weight	8 ² 64	8 ¹ 8	8 ⁰ 1
Value x Weight	6 x 64	2 x 8	4 x 1
Sum	384	16	4

4

Hexadecimal (Base 16 Integers)

1. The possible digits in a hexadecimal number are:

0, 1, 2, 3, 4, 5, 6, 7, 8, 9, A, B, C, D, E, F

where A, B, C, D, E, F stand for 10, 11, 12, 13, 14, 15 in decimal respectively.

2. The actual value (in base 10) represented by the hexadecimal digit sequence $A_{n-1}...A_1A_0$ is: $\sum_{i=0}^{n-1}a_i\times 16^i$

Position	3	3 2		0	
Weight	16 ³ 4,096	16 ² 256	16¹ 16	16 ⁰ 1	
Value x Weight	6 x 4,096	7 x 256	0 x 16	4 x 1	
Sum	24,576	1,792	0	4	

Conversion from other bases to Base 10

• Convert the following numbers to Base 10:

$$AEC_{16} = 10x16^2 + 14x16^1 + 12x16^0 = 2796_{10}$$

$$17_8 = 1x8^1 + 7x8^0 = 15_{10}$$

$$77_5 = 7x5^1 + 7x5^0 = 42_{10}$$

$$10101_2 = 1 \times 2^4 + 0 \times 2^3 + 1 \times 2^2 + 0 \times 2^1 + 1 \times 2^0$$
$$= 21_{10}$$

45

Range of a Number System (Integers)

- The range of a number system is how many different numbers it can represent.
- The range R for K digits in Base B is:

$$R = B^K$$

• Conversely, the number of digits *K* required to represent a total of *R* numbers in a Base *B* number system is:

$$K = \lceil log_B R \rceil$$

Range of a Number System (Integers)

■ Example:

How many numbers can 1 bit represent? How about 4 bits?

```
1 bit, base 2 \rightarrow represents up to 2^1 or 2 values (0 or 1)
4 bits, base 2 \rightarrow represents up to 2^4 or 16 values (0000, 0001, 0010, ..., 1111)
```

How many numbers can 2 digits in Base 8 represent?

2 digits , base 8 \rightarrow represents up to 8² or 64values

47

Range of a Number System (Integers)

Example:

How many bits are required to represent 32, 64, 1024, 40 and 100 values?

```
32 \rightarrow requires \lceil log_2 32 \rceil or 5 bits
64 \rightarrow requires \lceil log_2 64 \rceil or 6 bits
1024 \rightarrow requires \lceil log_2 1024 \rceil or 10 bits
40 \rightarrow requires \lceil log_2 40 \rceil or 6 bits
100 \rightarrow requires \lceil log_2 100 \rceil or 7 bits
```

Fractions

- A number with fractional part (example 15.35₁₀ in Base 10) is a sequence of digits, followed by a decimal point or radix point in general, and then a sequence of digits:
- Radix point separates the integral part (with positive powers of the base, with value ≥1 and ≤0) from the fractional part (with negative powers of the base, with 1<value<0).

$$a_n \dots a_0 \cdot a_{-1} \dots a_{-k}$$

a_n: most significant digit; a_{-k}: least significant digit

 For the fractional part, the successive digits have the following values

or equivalently

where B is the base of the number

49

Fractions

• 0.101011₂ = **0.671875**₁₀

Position	-1	-2	-3	-4	-5	-6
Weight	2 -1	2 -2	2 -3	2-4	2 -5	2 -6
	1/2	1/4	1/8	1/16	1/32	1/64
Value x Weight	1 x 1/2	0 x 1/4	1x 1/8	0 x 1/16	1 x 1/32	1 x 1/64
Sum	.5		0.125		0.03125	0.015625

•
$$15.35_{10}$$
 = $1 \times 10^1 + 5 \times 10^0 + 3 \times 10^{-1} + 5 \times 10^{-2}$

• 6F.77₁₆ =
$$6 \times 16^{1} + 15 \times 16^{0} + 7 \times 16^{-1} + 7 \times 16^{-2}$$

= 111.46484375_{10}

•
$$101.01_2 = 1 \times 2^2 + 1 \times 2^0 + 1 \times 2^{-2}$$

= 5.25_{10}

Fractions

Example:

• Convert A3F.C₁₆ to decimal

A3F.C₁₆=
$$10 \times 16^2 + 3 \times 16^1 + 15 \times 16^0 + 12 \times 16^{-1}$$

= 2623.75_{10}

• Convert 132.7₈ to decimal

$$132.7_8 = 1 \times 8^2 + 3 \times 8^1 + 2 \times 8^0 + 7 \times 8^{-1}$$

= 90.875₁₀

51

Fractions

• Example:

$$0.011_2 = 0 \times 2^{-1} + 1 \times 2^{-2} + 1 \times 2^{-3}$$

= 0.0 + 0.25 + 0.125
= 0.375₁₀

- There may NOT be an **exact** relationship between fractional numbers in different number base. For example:
 - 0.1_{10} cannot be represented exactly in binary (Base 2) Equivalent value is $0.0001100110011..._2$
 - 0.1_3 cannot be represented exactly in decimal (Base 10) Equivalent value $0.333333..._{10}$

Fractions

- Moving the radix point one place to the right multiplies the number by the base number. Example:
 - $-139.15_{10} \times 10^{1} = 1391.5_{10}$
 - $-139.15_{10} \times 10^2 = 13912_{10}$
 - $-101.11_2 \times 2^1 = 1011.1_2$ (or equivalently $5.75_{10} \times 2_{10} = 11.5_{10}$)
 - $-101.11_2 \times 2^3 = 101110_2$ (or equivalently $5.75_{10} \times 8_{10} = 46_{10}$)
- Move the number point one place to the left divides the number by the base number. Example:
 - $-139.15_{10}/10^{1} = 13.915_{10}$
 - $-139.15_{10} / 10^2 = 1.3915_{10}$
 - $-\ 101.11_2\ /\ 2^1\ = 10.111_2 \qquad \text{(or equivalently } 5.75_{10}\ /\ 2_{10}\ = 2.875_{10}\text{)}$
 - $-101.11_2/2^3 = 0.10111_2$ (or equivalently $5.75_{10}/8_{10} = 0.71875_{10}$)

53

Review Question

Question 1:

Convert the following value to Base 10:

- a) FF02₁₆
- b) 776₈
- c) 1001 0110₂

Question 2:

How many numbers can be represented using

- a) Base 10, 2 digits
- b) Base 2, 16 digits

Question 3:

How much digits do we need to cover the unsigned value 23000 in Base 2, 10 and 16?