## **OPERATING INSTRUCTIONS**

The TV and any additional A/V sources added can now be viewed from rear monitors. The TV-OUT interface will only replicate what is being viewed at the front screen and will not allow separate pictures to be viewed at the rear.



# **TVOUT-ALL**

## TV TUNER OUTPUT PORSCHE / MERCEDES / LR / RR With TV Tuner

NAV TV (Europe) LTD



## NAV TV (Europe) LTD

**Distribution Centre** Unit 21B Vale Business Park Llandow, Vale of Glamorgan CF71 7PF

Telephone: + 44 (0)8445 783 783 + 44 (0)1446 77 22 47 Fax:

technical@nav.tv

## **LOCATION & REMOVAL**

Installation is made at the GREEN FAKRA connector, on the Front monitor on all Models,

#### **PORSCHE**

First remove the trim surrounding the screen (trim clips only) then remove 4 screws



#### **RANGEROVER SPORT / LANDROVER 3**

Remove the radio surround trims and the radio top trim, then pull forward the leather side trims that cover the bottom screws of the air vents (circled below) Remove the 4 screws holding the air vents and remove.



holding the screen and remove

#### MERECEDES Removing the units varies;

#### ML/R

Open ashtray and remove two torx screws. then close ashtray and remove. Heater control panel can be pulled from bottom to remove. Next take out 2 torx screws below unit and pull down the 2 silver locking bars.



### **LOCATION & REMOVAL**

#### CLK/C/E/CLS

Remove gear selector gaiter and pull the trim bellow it (then remove 2 torx screws holding ashtray CLK/C only) and remove. (Next remove 2 more torx screws holding panel below the command .Pull panels above and below command to expose the 4 torx screws holding in the unit CLK/C only) For E/CLS rotate the two screws on the underside of the command to release the radio.

#### **RANGEROVER**

Remove the air vents L and R by pulling 4 tabs inside the vent (see fig 1) Next pull the dash side panels (trim clips only) Remove 4 screws each side securing the wood trim panels. Now remove the wood trim panels and unplug the lights and headlight switches. Unclip the centre speaker grille on the dash to access screws (see fig 2) Remove all exposed screws on top part of dash and pull away from windscreen (no need to unscrew centre speaker) Unplug centre speaker and remove top part of dash completely (see fig 3) Take out 4 screws at top of screen and 2 at either side behind wood trim (deep reach screwdriver needed)







## INSTALLATION

Connect the interface power harness;

to 12v+ ACC / IGN RED

**BLACK** to 12v- GROUND

Locate the GREEN FAKRA connector on the screen / radio unit,



Remove the GREEN FAKRA plug from the connector and install the supplied male plug to the female plug, and the supplied female plug the screen / radio connector. Next connect this harness to the interface position marked IN (TV signal IN)

Lastly connect your rear screen(s) to the interface positions marked

V1 (video 1) and V2 (video 2)

