

AV1LEX

A/V INPUT **LEXUS**

Without TV Tuner and with or without **DVD Changer**

NAV TV (Europe) LTD



NAV TV (Europe) LTD

Distribution Centre Unit 21B Vale Business Park Llandow, Vale of Glamorgan CF71 7PF

Telephone: + 44 (0)8445 783 783 Fax: + 44 (0)1446 77 22 47

technical@nav.tv

LOCATION & REMOVAL

Installation is made at the front screen and head unit.

To remove the front unit you need to access 4 bolts, 2 located behind the air vents and 2 located behind the ashtray assembly.

Once removed you may disconnect all plugs and remove the unit completely.

LEXUS IS/GS Models:



INSTALLATION

Video Input

The Video input is inserted at the **BLUE** 6 way plug located at the top of the unit, *labelled as 1 opposite for cars without DVD Changer.* Or at the Bottom **BLUE** plug, *labelled as 4 opposite for cars with DVD Changer.* The pins are inserted as follows;

Video signal Pin 1
Video shield Pin 4

Video signal Pin 3 (with DVDC)
Video ground Pin 6 (with DVDC)



Audio Input

The Audio input is inserted at the White 12 way plug located at the bottom of the unit (labelled as 3 opposite) The pins are inserted as follows;

Left signal pin 4

Left ground pin 5

Right signal pin 2

Right ground pin 3



AV1LEX interface

The AV1LEX interface is connected at the White 20 way plug (labelled as 2 opposite)

The connections are as follows:

RED to 12v Acc

BLACK to 12v- Ground

BLUE to PURPLE (pin5)

BLUE/WHITE to PINK (pin15)

OPERATING INSTRUCTIONS

With the interface installed you will now have an additional source in the menu via the MODE button. The source you have added can be chosen using the 'dip switches' inside the interface. Settings are as follows.

1	2	3	4	mode added
On	on	on	on	DVD changer
Off	on	on	on	DVD player
On	off	on	on	NAVIGATION
-	-	-	off	PAL input
-	-	-	on	NTSC input

Note:

You cannot add a source that is already fitted to the vehicle.

The audio and video from your added source will switch via the mode button as factory.



