

edet2sky

January 12, 2017

Abstract

Converts between XMM detector coordinates and sky coordinates.

1 Instruments/Modes

	Instrument	Mode	
MOS PN		imaging imaging	

2 Use

ningling propagaing	******	
pipeline processing	yes	
interactive analysis	yes	

3 Description

The task converts camera-centric positions on the detector, specified either in DETX/Y or RAWX/Y coordinates, into sky (X/Y) coordinates and celestial, RA/DEC positions. RAWX/Y coordinates must be specified together with a CCD number.

The DETX/Y focal-plane coordinates are the same system as the CAMCOORD2 system described in the Calibration Access and Data Handbook, except that the units of DETX/Y are 0.05 arcseconds rather than the millimetres of CAMCOORD2. RAWX/Y coordinates correspond to the PIXCOORD1 system and thus have units of CCD pixels. The position in this system depends on the readout node, which is specifiable via the parameter mosccdnode. (Note that this parameter is ignored if the instrument is PN, since its CCDs only have one readout node.) The default setting mosccdnode='primary' reflects the fact that nearly all the XMM EPIC MOS data has been taken with that node setting.

The source positions may either be specified one at a time on the command line (ie, 1 source per invocation of edet2sky; datastyle=user) or in bulk via a FITS file (datastyle=set). These two formats are described in more detail below.



3.1 Command-line position entry.

The detector position of a single source may be entered via the parameters X, Y, where the coordinate system is specified by inputunit which can be either "raw" or "det" for RAW or DETECTOR coordinates. If inputunit="raw" then the CCD number must be entered with the parameter ccd. Eg:

```
edet2sky datastyle=user inputunit=raw X=32 Y=190 ccd=4 calinfoset=imagepnxy.ds or
```

edet2sky datastyle=user inputunit=det X=-10000 Y=10000 calinfoset=imagemos1.ds

See the task **param** documentation for further details.

In this mode, the output positions are printed to the standard output. The format of the output lines is as follows irrespective of the units of the input coordinates.

```
# Instrument: EPN
# RA (deg)
             DEC (deg)
187.7579
            64.0481
# rawX
            rawY
                     ccd
                           On chip?
  28.95
            66.46
                      2
                             Т
# detX
               detY
 -10000.00
               10000.00
# Image X
             Y pixel
  343.86
             140.33
# Sky X
               Y pixel
  29872.94
               12165.86
```

Ouput contains coordinates in the systems, RA/DEC, RAW and Detector. If WCS information has been obtained from an input file (calinfoset='set') then the output includes the Image pixel and Sky pixel (POS). The 'Image pixel' coordinates refer to the pixel position in the input file given by the calinfoset parameter.

If you want to display the numbers only, add withheader='no' to the command line. In the case above, this would give

```
187.7579 64.0481

28.95 66.46 2 T

-10000.00 10000.00

343.86 140.33

29872.94 12165.86
```

For the convenience of script authors, the number fields for the output are given below:

```
Page:
      3
```

```
# Instrument: EPN
# RA (deg)
             DEC (deg)
            64.0481
187.7579
# rawX
            rawY
                    ccd
                           On chip?
+xxx.xx
          +xxx.xx
                    хx
                             x
# detX
               detY
+xxxxx.xx
              +xxxxx.xx
# Image X
             Y pixel
xxxx.xx
            xxxx.xx
# Sky X
               Y pixel
+xxxxxx+
              +xxxxx.xx
```

If inputunit='det' and the source does not fall on a CCD a warning message is issued; however the task still prints a RAWX/Y position, this being the position of the source in the RAWX/Y coordinate system of the nearest CCD. In this case the value of the 'On chip?' column is 'F' rather than 'T'.

If inputunit='raw' and the source does not fall on a CCD then the position is translated without a warning message.

3.2 FITS file positions

A list of input positions may be supplied in a FITS table by setting intab=file:table. In this case the task attempts to read positions from columns DETX and DETY, if inputunit='det' or columns RAWX, RAWX and CCDNR if inputunit='raw', from a file and table specified by the parameter intab.

There are two options for the output: either the output positions can be written to columns in the same file, or a new file can be created to contain them. If the former is desired, set withouttab='no'; if the latter, set withouttab='yes' and provide the name of the new dataset and table in outtab. The transformed position values are written to the columns RAWX, RAWY, CCDNR, FLAG, DETX, DETY, RA, DEC, IMAGEX, IMAGEY, X and Y (see section 7 for a detailed description of the output format).

The value of FLAG is set to 0 unless a source does not fall on any CCD, in which case FLAG is set to 1. In these cases the values of RAWX, RAWY and CCDNR represent positions relative to the nearest CCD.

An example of input from a file mos_raw.fits, containing a set of raw coordinate positions in an extension called POSITIONS and writing the output coordinates into a table output in a file fullpos.ds, would be:

edet2sky intab=mos_raw.fits:POSITIONS calinfostyle=set calinfoset=mos_rev2730_im.ds inputunit=raw outtab=fullpos.ds:output

3.3 Task requirements.

The task clearly needs to know the direction in space of the focal axis of the relevant instrument at the time of the observation of interest. There are three necessary pieces of information: the name of the



XMM-Newton Science Analysis System

Page:

instrument, the date-time of the observation and the spacecraft pointing direction (attitude) at this time. The task processes these as follows: the instrument identification and the observation date-time are used together to calculate (from values stored in the CCF) the instrument boresight correction at the time of the observation; this correction is then applied to the spacecraft pointing.

There are two ways to pass the 'cal' information to edet2sky, governed by the parameter calinfostyle:

- 1. calinfostyle = 'set': the information is sought from INSTRUME, DATE-OBS etc keywords in the header of the source list specified by calinfoset. These should be found in the primary headers of all XMM product data sets. It is recommended to use the source list itself as the calinfoset, provided it is an XMM product, and from the same instrument.
- 2. calinfostyle = 'user': the information must be provided by the user via the parameters instrument, datetime, scattra, scattdec and scattapos.

In order to be able to apply the correct boresight correction, as well as to have access to the instrument specifications, the task requires access to the CCF components relevant to the dates of observation and analysis. This is achieved in the usual way by constructing a cif file with **cifbuild** and pointing to it with the environment variable SAS_CCF.

4 Parameters

This section documents the parameters recognized by this task (if any).

Parameter	Mand	Type	Default	Constraints
-----------	------	------	---------	-------------

datastyle	no	string	set	user—set

By use of this parameter, the user can specify the style of input and output desired. If datastyle='user', the task looks for position information for a single source in the parameters ra and dec. If datastyle='set', the task looks for the source positions stored in columns RA and DEC of a FITS table specified by the parameter intab.

intab	no	table	inset.ds:INPUT				
Name of the FITS table that	Name of the FITS table that contains the sky positions. Active only if datastyle='set'.						

, and a second of the second o

withouttab	no	boolean	no	
1 'C 1	1 TC	• /		. 1

Active only if datastyle='set'. If withouttab='yes', the task looks for outtab and writes the output to this file. Otherwise the output is written to columns in the intab.

outtab	no	table	outset.ds:OUTPUT	

Name of the FITS table that is to contain the camera-centric positions. Active only if datastyle='set' and withouttab='yes'.

X	yes	double	0.0	
The X coordinate of the inp	ut position.	Active onl	y if datastyle='user'.	This refers to a detector

The X coordinate of the input position. Active only if datastyle='user'. This refers to a detector coordinate if inputunit='det' or a raw chip coordinate if inputunit='raw'.

Y	yes	double	0.0	
The Y coordinate of the inp	ut position.	Active onl	y if datastyle='user'.	This refers to a detector
coordinate if inputunit='det	or a raw ch	nip coordina	te if inputunit='raw'.	

ccd	yes	integer	1	

XMM-Newton Science Analysis System

The CCD number relevant for an input RAW coordinate. Active only if datastyle='user' and inputunit='raw'.

Page:

5

withheader	no	boolean	yes	
			v	

Active only if datastyle='user'. If withheader='yes', the task prints some lines of header information before printing the source position lines; if 'no', this is omitted. The 'no' setting is convenient for those wishing to run edet2sky from a script.

This allows the user to specify the readout node for positions on the MOS instruments. It is enabled only if outunit='raw', and ignored for PN.

calinfostyle	no	string	set	set—user

If 'set' the task obtains information about the instrument and spacecraft pointing from calinfoset; if 'user', this information is obtained from parameters instrument, datetime, scattra, scattdec and scattapos.

calinfoset	yes	dataset	calinfo.ds	

The name of the dataset in which information about the instrument and spacecraft pointing etc is stored in keywords.

instrument	yes	string	EMOS1	EMOS1-	-EMOS2-	-EPN
A - time						

Active only if calinfostyle='user'. The name of the relevant XMM instrument.

	datetime	yes	string	00:00:00-00-00T00:00:00	
--	----------	-----	--------	-------------------------	--

If calinfostyle='user', the date and time are expected via this string parameter.

scattra	yes	angle	0.0	$0 \le \mathtt{attra} \le 360$

The right ascenscion (in any of the allowed angle-parameter formats) of the spacecraft pointing. Active only if calinfostyle='user'.

$\mathbf{scattdec}$	yes	angle	0.0	$-90 \le $ attdec ≤ 90

The declination (in any of the allowed angle-parameter formats) of the spacecraft pointing. Active only if calinfostyle='user'.

scattapos	yes	angle	0.0	$0 \leq \mathtt{attapos} \leq 360$

The position angle (in any of the allowed angle-parameter formats) of the spacecraft pointing. Active only if calinfostyle='user'.

5 Errors

This section documents warnings and errors generated by this task (if any). Note that warnings and errors can also be generated in the SAS infrastructure libraries, in which case they would not be documented here. Refer to the index of all errors and warnings available in the HTML version of the SAS documentation.

badCalInfoStyle (error)

The value of the calinfostyle parameter was not recognised.

XMM-Newton Science Analysis System

Page: 6

The value of the mosccdnode parameter was not recognised.

badInpUnit (error)

The value of the inputunit parameter was not recognised.

badDataStyle (error)

The value of the datastyle parameter was not recognised.

emptyTableName (error)

Parameter outtab was not given in the form dataSetName:tableName.

notOnChip (warning)

The calculated raw XY position does not fall on any ccd corrective action: The task (i) calculates the RAWX/Y position relative to the nearest chip; (ii) either sets the FLAG column to 1 or writes F under 'On chip?' in the output, depending on the value of datastyle.

6 Input Files

- 1. Required only if datastyle='set': a source list in the form of a FITS table intab containing the following columns:
 - DETX.
 - DETY.

if inputunit='det' or

- RAWX.
- RAWY.
- CCDNR.

if inputunit='raw'. All data types may be either REAL32 or REAL64.

2. Required only if calinfostyle='set': an XMM product file containing keywords INSTRUME, DATE-OBS, RA_PNT, DEC_PNT and PA_PNT. It also needs to contain the WCS keywords, CRPIX1 etc. to allow conversion to image pixels. A further set of keywords, REFXCRPX etc. allow translation to an X/Y tangential plane coordinate system.



7 Output Files

Written only if datastyle='set': a FITS table containing the following columns:

- A 32-bit real column RAWX, in units of CCD pixels.
- A 32-bit real column RAWY, in units of CCD pixels.
- An 8-bit integer column CCDNR
- A 32-bit integer column FLAG
- A 32-bit real column DETX, in 0.05 arcsec.
- A 32-bit real column DETY, in 0.05 arcsec.
- A 64-bit column RA, in degrees.
- A 64-bit column DEC, in degrees.
- A 32-bit real column IMAGEX, in units of image pixels
- A 32-bit real column IMAGEY, in units of image pixels.
- A 32-bit real column X, in units of sky pixels
- A 32-bit real column Y, in units of sky pixels.

If withouttab='yes', a new dataset outtab is constructed to hold these columns; if 'no', they are written to the intab.

8 Algorithm

Coordinate transformations are implemented using the appropriate cal calls and the routines in ssclib.

9 Comments

This is an adaption of esky2det, written by Ian Stewart and Masa Sakano.

References