
## Replacement Remote for Security+ Family / Billion Code

## Installation Manual

**Programming Instructions for** 







Locate the Smart / Learn button on your garage door opener (you will need a ladder).

Learn LED

## Check the Working Mode on Remote

The remote has two working modes for different garage door opener types.



To check the working mode. Just press and hold the button Then observe LFD status.

LED Status	Mode #	For Opener Type
SOLID	Mode 1	Purple/ Red/Orange
FLASHING	Mode 2	Yellow/ Green

### Check above table.

Does remote button's working mode match your opener's learn button color (as seen in Step 1)?

If ves. proceed to Step 3

If no, you will need to change working mode first, proceed to Step 4

## **Garage Door Opener Learning**

**Change the Working Mode on** 

Press the learn button on the back of the opener. After the learn LED glows steadily. press and hold the button on the remote until the opener lights flash or you

hear two clicks. At that point, the remote is successfully programmed.



# **Troubleshooting**



### Try change remote's working mode

Double-check if the working mode on the remote matches your opener's learn button color. Sometimes, the learn button color may be incorrect. In that case, please try changing to another mode; it might work.



### Automatically deactivated old remote?

If your opener's memory is full, try erasing the garage opener's memory according to the motor unit owner's manual, and then reprogram.



### It stopped working after a few weeks

Replace the CR2032 Battery when the remote stops working after a few



### Have garage door closed first

Sometimes, door must be closed before



### The Learn LED glow steadily

Ensure that the Learn LED glows steadily when performing Step 3.

1. Using the Visor Clip to press and hold the "PROG" button on the back of the remote for 3 seconds until the LED flashes, then release.

Remote

