Closed Loop ComCam Image Ingestion and Application of Correction

This notebook is used to execute the [LVV-2229 (2.0)] test script during System Spread Integration Tests on Level 3.

It is part of the plan LVV-P81 and of the test cylce LVV-C176.

Execution steps are separated by horizontal lines.

Upon completion, save the notebook and its output as a pdf file to be attached to the test execution in JIRA.

LVV-T2229 (2.0) simply repeats the LVV-T2228 (1.0) test case twice, but with different targets.

This simulates two visits and tell us how the MTAOS behaves on sky.

The idea is that, depending on the angular distance between the two targets, the MTAOS should use or not the corrections applied from the previous target.

```
In []: from lsst.ts import utils

# Extract your name from the Jupyter Hub
    __executed_by__ = os.environ["JUPYTERHUB_USER"]

# Extract execution date
    __executed_on__ = utils.astropy_time_from_tai_unix(utils.current_tai())
    __executed_on__.format = "isot"

# This is used later to define where Butler stores the images
summit = os.environ["LSST_DDS_PARTITION_PREFIX"] == "summit"

print(f"\nExecuted by { __executed_by__} on { __executed_on__}."
    f"\n At the summit? {summit}")
```

about:srcdoc Page 1 of 17

Initial Setup

log onto the summit nublado https://summit-lsp.lsst.codes/ git clone the ts_notebook repo

There will be a series of procedures to set up, "slew" and track the telescope before we get an image.

This is similar to test case LVV-T2189.

Check ComCam Playback Mode

Verify that ComCam can be use the playback option and that the required images are stored in the right place **TBD**.

about:srcdoc Page 2 of 17

Load all the needed libraries

Using the setup procedure, get the remotes and the components ready.

This includes simulators as well as real hardware when available (this will depend on when the test is conducted at NCSA or on level 3 or on the telescope):

- pointing
- mount (with the CCW)
- rotator
- ready M1M3: raise mirror, turn on FB, clear forces. Note that if used at level 3, we need to have M1M3 LUT use mount telemetry
- ready M2: turn on FB, clear forces. Note that if used at level 3, we need to have M2
 LUT use mount telemetry
- Get cam hex Ready: check config; make sure LUT is on and has valid inputs; make sure hex is at LUT position
- Get M2 hex (simulator) Ready: check config; make sure LUT is on and has valid inputs; make sure hex is at LUT position
- Finally, get the MTAOS CSC ready

```
In [1]: %load_ext autoreload
%autoreload 2

In [2]: import rubin_jupyter_utils.lab.notebook as nb
nb.utils.get_node()

/tmp/ipykernel_26104/1665379685.py:2: DeprecationWarning: Call to deprecated function (or staticmethod) get_node. (Please use lsst.rsp.get_node())
    nb.utils.get_node()

Out[2]: 'yagan04'
```

about:srcdoc Page 3 of 17

```
In [3]:
        import os
        import sys
        import asyncio
        import logging
        import pandas as pd
        import numpy as np
        from matplotlib import pyplot as plt
        import lsst.daf.butler as dafButler
        from lsst.ts import salobj
        from lsst.ts.observatory.control.maintel import MTCS, ComCam
        from lsst.ts.observatory.control import RotType
        lsst.ts.utils.tai INFO: Update leap second table
        lsst.ts.utils.tai INFO: current_tai uses the system TAI clock
In [4]: logging.basicConfig(format="%(name)s:%(message)s", level=logging.DEBUG)
In [5]: log = logging.getLogger("setup")
        log.level = logging.DEBUG
In [6]: domain = salobj.Domain()
In [7]: mtcs = MTCS(domain=domain, log=log)
        mtcs.set rem loglevel(40)
        setup.MTCS DEBUG: mtmount: Adding all resources.
        setup.MTCS DEBUG: mtptg: Adding all resources.
        setup.MTCS DEBUG: mtaos: Adding all resources.
        setup.MTCS DEBUG: mtm1m3: Adding all resources.
        setup.MTCS DEBUG: mtm2: Adding all resources.
        setup.MTCS DEBUG: mthexapod 1: Adding all resources.
        setup.MTCS DEBUG: mthexapod_2: Adding all resources.
        setup.MTCS DEBUG: mtrotator: Adding all resources.
        setup.MTCS DEBUG: mtdome: Adding all resources.
        setup.MTCS DEBUG: mtdometrajectory: Adding all resources.
        MTHexapod INFO: Read historical data in 0.03 sec
        MTHexapod INFO: Read historical data in 0.05 sec
In [8]: await mtcs.start task
Out[8]: [None, None, None, None, None, None, None, None, None]
In [9]: comcam = ComCam(domain=domain, log=log)
        comcam.set rem loglevel(40)
```

about:srcdoc Page 4 of 17

```
setup.ComCam DEBUG: cccamera: Adding all resources.
         setup.ComCam DEBUG: ccheaderservice: Adding all resources.
         setup.ComCam DEBUG: ccarchiver: Adding all resources.
In [10]: await comcam.start task
         [None, None, None]
Out[10]:
In [11]:
         await comcam.enable()
         setup.ComCam INFO: Enabling all components
         setup.ComCam DEBUG: Gathering settings.
          setup.ComCam DEBUG: Couldn't get settingVersions event. Using empty sett
         ings.
          setup.ComCam DEBUG: Couldn't get settingVersions event. Using empty sett
         setup.ComCam DEBUG: Complete settings for cccamera.
         setup.ComCam DEBUG: Complete settings for ccheaderservice.
         setup.ComCam DEBUG: Complete settings for ccarchiver.
         setup.ComCam DEBUG: Settings versions: {'cccamera': '', 'ccheaderservice
         ': '', 'ccarchiver': ''}
         setup.ComCam DEBUG: [cccamera]::[<State.ENABLED: 2>]
         setup.ComCam DEBUG: [ccheaderservice]::[<State.ENABLED: 2>]
         setup.ComCam DEBUG: [ccarchiver]::[<State.ENABLED: 2>]
         setup.ComCam INFO: All components in <State.ENABLED: 2>.
```

Slew and Track

Using the slew procedure, slew the systems to a specific elevation, azimuth and rotator angle. Verify that the telemetry is generated.

Slew to RA 20:28:18.74 and DEC -87:28:19.9 with rot_type=RotType.Physical and Rotator Angle of 0°. We use this field because it is the field that was simulated and that is a field that is visible the whole year.

RotType Physical Ensures that the Rotator will not move. This is necessary because the CCW is not running (MTmount in simulation mode).

Slew to target:

```
In [12]: await mtcs.slew_icrs(ra="20:28:18.74", dec="-87:28:19.9", rot_type=RotType.F
```

about:srcdoc Page 5 of 17

```
setup.MTCS DEBUG: Setting rotator to physical fixed position 0.0 deg. Ro
tator will not track.
setup.MTCS WARNING: Camera cable wrap following disabled in MTMount.
setup.MTCS DEBUG: Wait 5.0s for rotator to settle down.
setup.MTCS DEBUG: Workaround for rotator trajectory problem. Moving rota
tor to its current position: 1.66
setup.MTCS DEBUG: Wait for MTRotator in position event.
setup.MTCS DEBUG: MTRotator in position: False.
setup.MTCS INFO: MTRotator in position: True.
setup.MTCS DEBUG: MTRotator in position True. Waiting settle time 5.0s
setup.MTCS DEBUG: Sending slew command.
setup.MTCS DEBUG: Scheduling check coroutines
setup.MTCS DEBUG: process as completed...
setup.MTCS DEBUG: Monitor position started.
setup.MTCS DEBUG: Waiting for Target event from mtmount.
setup.MTCS DEBUG: mtmount: <State.ENABLED: 2>
setup.MTCS DEBUG: mtptg: <State.ENABLED: 2>
setup.MTCS DEBUG: mtaos: <State.ENABLED: 2>
setup.MTCS DEBUG: mtm1m3: <State.ENABLED: 2>
setup.MTCS DEBUG: mtm2: <State.ENABLED: 2>
setup.MTCS DEBUG: mthexapod 1: <State.ENABLED: 2>
setup.MTCS DEBUG: mthexapod 2: <State.ENABLED: 2>
setup.MTCS DEBUG: mtrotator: <State.ENABLED: 2>
setup.MTCS DEBUG: mtdome: <State.ENABLED: 2>
setup.MTCS DEBUG: mtdometrajectory: <State.ENABLED: 2>
setup.MTCS DEBUG: Wait for mtmount in position events.
setup.MTCS DEBUG: Wait for dome in position event.
setup.MTCS DEBUG: Wait for MTRotator in position event.
setup.MTCS DEBUG: MTRotator in position: True.
setup.MTCS DEBUG: MTRotator already in position. Handling potential race
condition.
setup.MTCS DEBUG: Wait for MTMount elevation in position event.
setup.MTCS DEBUG: MTMount elevation in position: False.
setup.MTCS DEBUG: Wait for MTMount azimuth in position event.
setup.MTCS DEBUG: MTMount azimuth in position: False.
setup.MTCS DEBUG: Mount target: private revCode: bdcb00ba, private sndSt
amp: 1647976873.2471752, private rcvStamp: 1647976873.247737, private se
qNum: 8932, private_identity: MTMount, private_origin: 11345, elevation:
30.22061612731386, elevationVelocity: -0.00018974111014833205, azimuth:
183.0157543334537, azimuthVelocity: -6.684477842736761e-06, taiTime: 164
7976873.3055394, trackId: 1, tracksys: SIDEREAL, radesys: ICRS, priority
setup.MTCS DEBUG: [Tel]: Az = +120.833[ +62.2]; El = +060.413[ -30.2] [R
ot]: +001.660[ -0.0] [Dome] Az = +000.000; El = +000.000
setup.MTCS DEBUG: Dome azimuth in position.
```

about:srcdoc Page 6 of 17

```
setup.MTCS DEBUG: Dome elevation in position.
         setup.MTCS INFO: MTRotator in position: False.
         setup.MTCS INFO: MTRotator in position: True.
         setup.MTCS DEBUG: MTRotator in position True. Waiting settle time 3.0s
         setup.MTCS DEBUG: [Tel]: Az = +158.777[ +24.2]; El = +041.456[ -11.2] [R
         ot]: +000.000[ -0.0] [Dome] Az = +000.000; El = +000.000
         setup.MTCS INFO: MTMount elevation in position: True.
         setup.MTCS DEBUG: MTMount elevation in position True. Waiting settle tim
         e 3.0s
         setup.MTCS INFO: MTMount azimuth in position: True.
         setup.MTCS DEBUG: MTMount azimuth in position True. Waiting settle time
         3.0s
         setup.MTCS DEBUG: [Tel]: Az = +183.016[ +0.0]; El = +030.218[ +0.0] [R
         ot]: +000.000[ +0.0] [Dome] Az = +000.000; El = +000.000
         (<ICRS Coordinate: (ra, dec) in deg
Out[12]:
              (307.07808333, -87.47219444) >
          <Angle 0. deg>)
```

Take in-focus image

Once the different components are ready (M1M3, M2, rotator and CCW, hexapods) and tracking, take an image using the take_image command in playback mode.

This second image should be the one that uses the correction calculated with the first slew.

```
In [13]: exp_focus = await comcam.take_object(15)
    print(f"Target exposure: {exp_focus}")

setup.ComCam DEBUG: Generating group_id
    setup.ComCam DEBUG: imagetype: OBJECT, TCS synchronization not configure
    d.
    setup.ComCam DEBUG: OBJECT 0001 - 0001
    Target exposure: [2022032200005]
```

Intra Focus Position

Using the Camera Hexapod, piston ComCam +1mm

```
In [14]: await mtcs.rem.mthexapod_1.cmd_offset.set_start(z=1000.)

Out[14]: <ddsutil.MTHexapod_ackcmd_c4d6958b at 0x7fbc24149100>
```

about:srcdoc Page 7 of 17

Intra Focus Image

While tracking, take an image with ComCam and check that the header is containing the right telemetry

```
In [15]: exp_intra = await comcam.take_object(15)
    print(f"Target 1 exposure: {exp_intra}")

setup.ComCam DEBUG: Generating group_id
    setup.ComCam DEBUG: imagetype: OBJECT, TCS synchronization not configure
    d.
    setup.ComCam DEBUG: OBJECT 0001 - 0001
    Target 1 exposure: [2022032200006]
```

Extra Focus Position

Using the Camera Hexapod, piston ComCam to -1mm

```
In [16]: await mtcs.rem.mthexapod_1.cmd_offset.set_start(z=-2000.)
Out[16]: <ddsutil.MTHexapod_ackcmd_c4d6958b at 0x7fbc2cf634c0>
```

Extra Focus Image

While tracking, take an image with ComCam and check that the header is containing the right telemetry.

```
In [17]: exp_extra = await comcam.take_object(15)
    print(f"Target 1 exposure: {exp_extra}")

setup.ComCam DEBUG: Generating group_id
    setup.ComCam DEBUG: imagetype: OBJECT, TCS synchronization not configure
    d.
    setup.ComCam DEBUG: OBJECT 0001 - 0001
    Target 1 exposure: [2022032200007]
```

about:srcdoc Page 8 of 17

Go Back to Focus Position

Put the hexapod back to 0mm.

```
In [18]: await mtcs.rem.mthexapod_1.cmd_offset.set_start(z=1000.)
Out[18]: <ddsutil.MTHexapod_ackcmd_c4d6958b at 0x7fbc2cbef5e0>
```

Stop Tracking

If using MTMount Simulator and CCW Following Mode Disabled, stop tracking to prevent the Rotator to hit the limit switches.

```
In [19]: await mtcs.stop_tracking()
setup.MTCS DEBUG: Stop tracking.
```

Get Zernike Coefficients

Use the MTAOS Wavefront Estimator Pipeline to calculate the required Zernike Coefficients that represent the Wavefront data.

```
In []: await mtcs.rem.mtaos.cmd_runWEP.set_start(visitId=exp_intra[0] - 20211119000 extraId=exp_extra[0] - 20211119000
```

Get Corrections

Use the MTAOS Optical Feedback Controller to retrieve the corrections that should be applied to m1m3, m2, camera hexapod, and m2 hexapod.

```
In [ ]: await mtcs.rem.mtaos.cmd_runOFC.start(timeout=60.)
```

about:srcdoc Page 9 of 17

Issue the corrections

Issue the corrections found by the MTAOS OFC to m1m3, m2, camera hexapod, and m2 hexapod.

```
In [ ]: await mtcs.rem.mtaos.cmd_issueCorrection.start(timeout=60.)
```

Verify ISR Data

Make sure that the Instrument Signature Removal ran on the intra- and extra-focus data and that this data is accessible via Butler.

about:srcdoc Page 10 of 17

```
In [ ]: %matplotlib inline
        fig, ax = plt.subplots(num="Intra Focus Image", figsize=(7,7), dpi=90)
        vmin = np.percentile(raw intra.image.array, 2)
        vmax = np.percentile(raw intra.image.array, 98)
        ax.imshow(raw_intra.image.array,
                  origin='lower',
                  interpolation='nearest',
                  vmin=vmin,
                  vmax=vmax)
        ax.set_xlabel("X [px]")
        ax.set_ylabel("Y [px]")
        fig.suptitle(f"Intra Focus Image\n{exp intra id['exposure']}")
        fig.tight layout()
        plt.show()
In [ ]: exp_extra_id = {'instrument': 'LSSTComCam',
                         'detector': 0,
                         'exposure': exp extra[0]}
        exp_extra = butler.get('postISRCCD', dataId=exp_extra_id,
                                collections=collections)
        print(exp_extra.getMetadata())
In []: %matplotlib inline
        fig, ax = plt.subplots(num="Extra Focus Image", figsize=(7, 7), dpi=90)
        vmin = np.percentile(exp extra.image.array, 2)
        vmax = np.percentile(exp_extra.image.array, 98)
        ax.imshow(exp extra.image.array,
                  origin='lower',
                  interpolation='nearest',
                  vmin=vmin,
                  vmax=vmax)
        ax.set_xlabel("X [px]")
        ax.set_ylabel("Y [px]")
        fig.suptitle(f"Extra Focus Image\n{exp_extra_id['exposure']}")
        fig.tight_layout()
        plt.show()
```

about:srcdoc Page 11 of 17

Slew and Track Second Target

Now, slew to a second target. The coordinates for this targets are **TBD** and depend on new simulated data. You will probably not run this for now until we have new simulated data. We will leave the notebook simply to have the structure pre-define.

Slew to **RA TBD** and **DEC TBD** with **rot_type=RotType.Physical** and **Rotator Angle of 0**°.

RotType Physical Ensures that the Rotator will not move. This is necessary because the CCW is not running (MTmount in simulation mode).

```
In [ ]: await mtcs.slew_icrs(ra=???, dec=???, rot_type=RotType.Physical, rot=0)
```

Take in-focus image 2

Once the different components are ready (M1M3, M2, rotator and CCW, hexapods) and tracking, take an image using the take_image command in playback mode. This second image should be the one that uses the correction calculated with the first slew.

```
In [ ]: exp_focus2 = await comcam.take_object(15)
    print(f"Target exposure: {exp_focus2}")
```

Intra Focus Position 2

Using the Camera Hexapod, piston ComCam +1mm.

```
In [ ]: await mtcs.rem.mthexapod_1.cmd_offset.set_start(z=1000.)
```

about:srcdoc Page 12 of 17

Intre Focus Image 2

While tracking, take an image and check that the header is containing the right telemetry.

```
In [ ]: exp_intra2 = await comcam.take_object(15)
    print(f"Target 1 exposure: {exp_intra2}")
```

Extra Focus Position 2

Apply an offset of -2000 um to the Camera Hexapod, to bring it down to -1 mm.

```
In [ ]: await mtcs.rem.mthexapod_1.cmd_offset.set_start(z=-2000.)
```

Extra Focus Image 2

While tracking, take an image and check that the header is containing the right telemetry

```
In [ ]: exp_extra2 = await comcam.take_object(15)
    print(f"Target 1 exposure: {exp_extra2}")
```

Go back to focus position 2

Send the hexapod back to 0 mm by applying an offset of 1000 um in Z.

```
In [ ]: await mtcs.rem.mthexapod_1.cmd_offset.set_start(z=1000.)
```

about:srcdoc Page 13 of 17

Stop tracking 2

If using MTMount Simulator and CCW Following Mode Disabled, stop tracking to prevent the Rotator to hit the limit switches.

```
In [ ]: await mtcs.stop_tracking()
```

Get Zernikes Coefficients 2

Use the MTAOS to calculate the required offsets to be sent to M1M3, M2, and the hexapods.

When we run the command in the example code below, if it does not raise the **TBD** error, then we know that the MTAOS WEP could find and retrieve the calibration files.

Get Corrections 2

Apply the resulting offsets to the M1M3, M2 and the hexapods

```
In [ ]: await mtcs.rem.mtaos.cmd_runOFC.start(timeout=60.)
```

Issue the corrections 2

Issue (apply) the corrections found by the MTAOS OFC to m1m3, m2, camera hexapod, and m2 hexapod.

```
In [ ]: await mtcs.rem.mtaos.cmd_issueCorrection.start(timeout=60.)
```

about:srcdoc Page 14 of 17

Verify Offsets TBD</h2>

Verify that the offsets are the expected one by plotting:

- m1m3 actuator 101 z force
- m2 actuator B1 force
- camera hex y position
- m2 hex y position
- What about others?

Wrap Up and Shut Down

This section is intended for shutting down the system and should not be run as part of the regular testing procedure. Only run the following cells if you are done with the system and don't plan on executing any further tests.

```
In [20]: await mtcs.set state(salobj.State.STANDBY, components=["mtaos"])
         setup.MTCS DEBUG: [mtaos]::[<State.ENABLED: 2>, <State.DISABLED: 1>, <St</pre>
         ate.STANDBY: 5>]
         setup.MTCS INFO: All components in <State.STANDBY: 5>.
In [21]: await mtcs.lower_m1m3()
         setup.MTCS DEBUG: M1M3 current detailed state {<DetailedState.ACTIVEENGI</pre>
         NEERING: 11>, <DetailedState.ACTIVE: 7>}, executing command...
         setup.MTCS DEBUG: process as completed...
         setup.MTCS DEBUG: M1M3 detailed state 8
         setup.MTCS DEBUG: mtm1m3: <State.ENABLED: 2>
         setup.MTCS DEBUG: mtm1m3: <State.ENABLED: 2>
         setup.MTCS DEBUG: M1M3 detailed state 5
In [22]: await mtcs.set state(salobj.State.STANDBY, components=["mtm1m3"])
         setup.MTCS DEBUG: [mtm1m3]::[<State.STANDBY: 5>, <State.OFFLINE: 4>]
         setup.MTCS INFO: All components in <State.OFFLINE: 4>.
In [23]: await mtcs.set state(salobj.State.STANDBY, components=["mtm2"])
```

about:srcdoc Page 15 of 17

```
setup.MTCS DEBUG: [mtm2]::[<State.ENABLED: 2>, <State.DISABLED: 1>, <Sta</pre>
         te.STANDBY: 5>1
         setup.MTCS INFO: All components in <State.STANDBY: 5>.
In [24]: await mtcs.set state(salobj.State.STANDBY, components=["mthexapod 1"])
         setup.MTCS DEBUG: [mthexapod_1]::[<State.ENABLED: 2>, <State.DISABLED: 1</pre>
         >, <State.STANDBY: 5>]
         setup.MTCS INFO: All components in <State.STANDBY: 5>.
In [25]: await mtcs.set state(salobj.State.STANDBY, components=["mthexapod 2"])
         setup.MTCS DEBUG: [mthexapod_2]::[<State.ENABLED: 2>, <State.DISABLED: 1</pre>
         >, <State.STANDBY: 5>]
         setup.MTCS INFO: All components in <State.STANDBY: 5>.
In [26]: await mtcs.standby()
         setup.MTCS DEBUG: [mtmount]::[<State.ENABLED: 2>, <State.DISABLED: 1>, <</pre>
         State.STANDBY: 5>]
          setup.MTCS DEBUG: [mtptg]::[<State.ENABLED: 2>, <State.DISABLED: 1>, <St</pre>
         ate.STANDBY: 5>]
         setup.MTCS DEBUG: [mtaos]::[<State.STANDBY: 5>]
         setup.MTCS DEBUG: [mtm1m3]::[<State.STANDBY: 5>]
         setup.MTCS DEBUG: [mtm2]::[<State.STANDBY: 5>]
         setup.MTCS DEBUG: [mthexapod 1]::[<State.STANDBY: 5>]
         setup.MTCS DEBUG: [mthexapod_2]::[<State.STANDBY: 5>]
         setup.MTCS DEBUG: [mtrotator]::[<State.ENABLED: 2>, <State.DISABLED: 1>,
         <State.STANDBY: 5>1
         setup.MTCS DEBUG: [mtdome]::[<State.ENABLED: 2>, <State.DISABLED: 1>, <S</pre>
         tate.STANDBY: 5>]
          setup.MTCS DEBUG: [mtdometrajectory]::[<State.ENABLED: 2>, <State.DISABL</pre>
          ED: 1>, <State.STANDBY: 5>]
         setup.MTCS INFO: All components in <State.STANDBY: 5>.
In [27]: await comcam.standby()
         setup.ComCam DEBUG: [cccamera]::[<State.ENABLED: 2>, <State.DISABLED: 1>
         . <State.STANDBY: 5>1
         setup.ComCam DEBUG: [ccheaderservice]::[<State.ENABLED: 2>, <State.DISAB</pre>
         LED: 1>, <State.STANDBY: 5>]
         setup.ComCam DEBUG: [ccarchiver]::[<State.ENABLED: 2>, <State.DISABLED:</pre>
         1>, <State.STANDBY: 5>]
         setup.ComCam INFO: All components in <State.STANDBY: 5>.
In [29]: await mtcs.set_state(salobj.State.OFFLINE, components=["mtmount"])
         setup.MTCS DEBUG: [mtmount]::[<State.STANDBY: 5>, <State.OFFLINE: 4>]
```

about:srcdoc Page 16 of 17

setup.MTCS INFO: All components in <State.OFFLINE: 4>.

In []:

about:srcdoc Page 17 of 17