Nonincendive Field Wiring. Wiring that enters or leaves an equipment enclosure and, under normal operating conditions of the equipment, is not capable, due to arcing or thermal effects, of igniting the flammable gas—air, vapor—air, or dust—air mixture. Normal operation includes opening, shorting, or grounding the field wiring. (CMP-14)

Informational Note: See ANSI/UL 121201, Nonincendive Electrical Equipment for Use in Class I and II, Division 2 and Class III, Divisions 1 and 2 Hazardous (Classified) Locations, for additional information.

Field wiring meeting this definition requires limitations of energy under normally expected conditions of operation, such as opening, shorting, or grounding. For example, stored energy in the form of mutual inductance or capacitance could be released during an opening, shorting, or grounding of nonincendive field wiring, which defeats the purpose of this protection technique.

△ Nonincendive Field Wiring Apparatus. Apparatus intended to be connected to nonincendive field wiring. (CMP-14)

Informational Note: See ANSI/UL 121201, Nonincendive Electrical Equipment for Use in Class I and II, Division 2 and Class III, Divisions 1 and 2 Hazardous (Classified) Locations, for additional information.

Nonlinear Load. A load where the wave shape of the steady-state current does not follow the wave shape of the applied voltage. (CMP-1)

Informational Note: Electronic equipment, electronic/electric-discharge lighting, adjustable-speed drive systems, and similar equipment may be nonlinear loads.

Nonlinear loads are a major cause of harmonic currents. Additional conductor heating is just one of the undesirable operational effects associated with harmonic currents. Informational Note No. 1(2) following 310.14(A)(3) points out that harmonic current is one of the factors that must be considered when determining the heat generated internally in a conductor.

Actual circuit measurements of current for nonlinear loads should be made using only true root-mean-square (rms) measuring ammeter instruments. Averaging ammeters produces inaccurate values if used to measure nonlinear loads.

See also

310.15(E)(3) and its commentary for more on nonlinear loads

- N Nonmetallic Extension. An assembly of two insulated conductors within a nonmetallic jacket or an extruded thermoplastic covering. The classification includes surface extensions intended for mounting directly on the surface of walls or ceilings. (CMP-6)
- Nonsparking. Constructed to minimize the risk of arcs or sparks capable of creating an ignition hazard during conditions of normal operation. (CMP-14)

Informational Note: See ANSI/UL 121201, Nonincendive Electrical Equipment for Use in Class I and II, Division 2 and Class III, Divisions 1 and 2 Hazardous (Classified) Locations, for additional information.

- N Normal/Emergency Power Source. A power source on the output side of a transfer switch or uninterruptible power supply that is automatically available upon loss of normal power. (700) (CMP-13)
- N Normal High-Water Level (as applies to electrical datum plane distances). Natural or Artificially Made Shorelines: An elevation delineating the highest water level that has been maintained for a sufficient period of time to leave evidence upon the landscape, commonly the point where the natural vegetation changes from predominantly aquatic to predominantly terrestrial.

Rivers and Streams: The elevation of the top of the bank of the channel. Streams, rivers, and tributaries that are prone to flooding and effects of water runoff shall consider the "bankfull stage" where an established gauge height at a given location along a river or stream, above which a rise in water surface will cause the river or stream to overflow the lowest natural stream bank somewhere in the corresponding reach.

Flood Control Bodies of Water: The flood pool maximum water surface elevation of a reservoir, equal to the elevation of the spillway.

Nonflood Control Bodies of Water: The flowage easement boundary in which the highest water surface elevation defined by the area existing between governmental-owned property line(s) and a contour line with perpetual rights to flood the area in connection with the operation of the reservoir. (CMP-7)

- N Nurses' Station. A space intended to provide a center of nursing activity for a group of nurses serving bed patients, where patient calls are received, nurses dispatched, nurses' notes written, inpatient charts prepared, and medications prepared for distribution to patients. Where such activities are carried on in more than one location within a nursing unit, all such separate spaces are considered a to be parts of the nurses' station. (517) (CMP-15)
- **N** Nursing Home. A building or portion of a building used on a 24-hour basis for the housing and nursing care of four or more persons who, because of mental or physical incapacity, might be unable to provide for their own needs and safety without the assistance of another person. [101:3.3.150.2] (CMP-15)
- N Office Furnishing. Cubicle panels, partitions, study carrels, workstations, desks, shelving systems, and storage units that may be mechanically and electrically interconnected to form an office furnishing system. (CMP-18)

Oil Immersion. Electrical equipment immersed in a protective liquid so that an explosive atmosphere that might be above the liquid or outside the enclosure cannot be ignited. (CMP-14)

Informational Note: See ANSI/UL 121201, Nonincendive Electrical Equipment for Use in Class I and II, Division 2 and Class III,