GETTING STARTED WITH MALAHIT-R1

Malahit-R1 is a portable SDR receiver that uses your mobile device, like a smartphone, for display and controls. The radio itself can be placed where reception is the best. It will then create a WiFi network, or connect to your existing WiFi network, and provide you with a user interface accessed through a web browser on your mobile device. The software inside *Malahit-R1* is based on the open-source *OpenWebRX+* project, while the proprietary hardware is developed by *Malahiteam*.

THINGS YOU NEED

You will need the following items to get started with your *Malahit-R1* remote SDR receiver:

1. **A smartphone, a tablet, or a computer** that will serve as display and control unit. Any device that runs a fairly recent web browser will do.

2. **Four 18650 rechargeable batteries** that will go inside the receiver. You can use fewer batteries if you like (they are all connected in parallel), but fewer batteries will obviously hold less power.

3. **A laptop power supply** with the USB-C connector, to charge batteries. Any power supply that supports PD standard should work. Less powerful QC power supplies are also compatible, but may not be able to run the receiver and charge it at the same time.

4. **Three meters of wire** for the loop antenna. By default, the receiver is configured to use a loop antenna for the best performance in urban areas. It also supports other antennas though, including a telescopic one.

SETTING THINGS UP

Once you have the above items, **follow the steps outlined below:**

1. Carefully unscrew and remove end covers, then open the receiver case. **Install your 18650 batteries** into the battery holder. Make sure you observe the correct polarity. Inserting batteries in the opposite polarity may damage the receiver. Close the receiver case and screw back the end covers.

2. **Bend your antenna wire into a loop** and attach its bare ends to the pair of terminal posts found on the receiver. Move your receiver close to a window, with the loop antenna standing up against that window.

3. **Use power supply** to plug your receiver into a power outlet. Then press and release the POWER button and wait for 15-30 seconds for the receiver to start.

4. On your smartphone, table, or computer, look at the available WiFi networks and **connect to the network** listed below:

   `network:  malahit-r1`

```
password: malahit-r1
```

5. Open a web browser of your choice and **go to the following web address**:

   ```
   http://192.168.10.1:8073/
   ```

   When the *Malahit-R1* web user interface loads, press the large arrow button, and start listening to the receiver. **You are all set!**

NEXT STEPS

Once you have your *Malahit-R1* running, please, **go through the following steps in order to finish setting up your receiver:**

1. Click on the *"Settings"* icon at the top-right corner of the web user interface. Then log into Settings by entering the following credentials:

   ```
   name:     admin
   password: malahit-r1
   ```

2. Click on *"General Settings"*, go to the bottom of the page, and **change your admin password** to something only you will know.

3. While at the *"General Settings"* page, you can also set up your receiver name, geographic location, the ITU region and country you are in, and other settings.

4. Once done with the *"General Settings"* page, click on *"Apply and Save"* to save the new password and other settings.

5. Go back to the main Settings page, click on *"WiFi Setup"*, and **enter the name and password for your local WiFi network**. You can have up to four different WiFi networks configured in the *"WiFi Setup"*.

6. While at the *"WiFi Setup"* page, you can also **change the name and password of the internal WiFi network** that gets activated when *Malahit-R1* cannot connect to any existing WiFi networks.

7. Once done with the *"WiFi Setup"* page, click on *"Apply and Save"* to save the new WiFi setup.

8. Click on the *"Help"* icon at the top of the web user interface to read the rest of the documentation and find out what else you can do with your *Malahit-R1* SDR receiver!

UPDATING SOFTWARE

Malahit-R1 runs Debian Linux and thus can be updated as any other Debian Linux device, by using *APT*. In order to update *Malahit-R1* software, follow these steps:

1. Connect your receiver to a local network using WiFi.

2. From another computer on the same local network, log into your receiver using SSH. Use the following credentials:

   ```
   name:     malahit
   ```

```
password: malahit-r1
```

3. Once logged in, make sure you **change the password** to something only you will know by typing this command:

```
passwd
```

4. Obtain the list of the latest software packages by typing this command:

```
sudo apt update
```

5. Upgrade your software to the latest versions by typing this command:

```
sudo apt upgrade
```

6. Disconnect from the receiver by typing this command:

```
exit
```

7. **If things go horribly wrong** for whatever reason, you can always download a fresh SD card image from the *Malahit* web site and rewrite your entire SD card with it, resetting the receiver to its factory settings.

©2026 Marat Fayzullin