ATA CODES

System Code 0 0	Sub Code	Description NONE SELECTED None Selected
5 5 5 5	0 20 21 43	MAINTENANCE CHECKS General Preventive/Periodic Maintenance FAA Qualification Prep INS/IRS/GPS Update
6 6 6 6 6 6 6 6 6 6 6 6 6 6 6	0 1 7 8 10 11 20 21 22 23 30 31 32 40 41 60 62 63	GENERAL General Non-STS Responsibilities Operator Error - Sim Eng Operator Error - STS Could Not Duplicate Works as Designed/ Works IAW Facility Systems Facility Power Facility Cooling/Heating Facility Fire Protection Operator Error Previously Entered Entered in Error ECO Accomplishment/Minor Mods SPR/Failure Report/ECO Generation Data Updates Simulator Navigation Data Base (See 80-20) Equip/Personnel Safety
11 11 11 11	0 10 20 30	PLACARDS AND MARKINGS General Exterior Paint Exterior Placards/Markings Interior Placards/Markings
21 21 21 21 21 21	0 8 26 30 60	AIR CONDITIONING General System Control Panel Equipment/Instrument Cooling Pressure Control/Indication Temp. Control System
22 22 22 22 22 22 22	0 10 11 20 21	AUTO FLIGHT General Control AP/Flt Guide Sys/Auto Flt Sys Flight Control Computer/Flight Augmentation C Speed/Attitude Correct/Auto Pitch Trim LSAS

System	Sub Code 23 30 35 40 70	Description Yaw Damper System Auto Throttles Thrust Rating PNL, Displays, Warnings System Monitor, MTP Approach Display/FMA
23 23 23 23 23 23 23 23 23 23 23 23 23 2	0 10 11 12 20 24 28 40 50 51 52 70 80	General COMMUNICATIONS VHF Communications Cockpit Speaker High Freq. (HF) Communication SELCAL Function ACARS/Printer Satellite Communications Interphone Audio Integrating System Crew Headphone Microphones Voice Recorder/ULB System Instructor Communication
24 24 24 24 24 24 24 24 24 24 24	0 8 10 20 22 30 32 40 50	ELECTRICAL POWER General Electrical System Control Panel Generator Drive(CSD)/Integrated Drive Gen(IDG) AC Gen & Control/Monitoring Emergency AC Power & ADG/RAT DC Gen & Control/Monitoring Emergency DC & Battery/Chrgr External Power AC Load Distribution/Bus Tie Cntrl DC Load Distribution
25 25 25 25 25 25 25	0 1 10 11 60	EQUIPMENT FURNISHINGS General APLC/PAT Batteries Flight Comp't Seats Emergency/Evacuation Equipment
26 26 26 26 26 26 26 26	0 10 11 12 13 20 21	FIRE PROTECTION General Engine Fire Detection System APU Fire Detection Smoke Detection Wing/Body Overheat Fixed Engine/Cargo Extinguishers Portable Extinguishers

System Code 26	Sub Code 30	Description Simulator Fire Protection/Smoke and Overheat
27		FLIGHT CONTROLS
27	0	General
27	1	Takeoff Warning
27	10	Aileron/Tabs/Ind & Control
27	20	Rudder/Tabs/Ind & Control
27	30	Elevator/Tabs/Ind & Control
27	32	Elevator Load Feel
27	40	Horizontal Stabilizer/Speed Trim
27	50	Flaps/Control/Indication
27	60	Spoiler/Spd. Brakes & Indication
27	80	Leading Edge Slats & Flaps/Indication
27	90	Simulator Control Loading System
27	91	Computer/ Reload
27	92	Interface/Cables
27	93	Servo Amp/Buffer Unit
27	94	Load Unit
27	95	Mechanical Linkage
27	96	Calibration/Alignment/Tuning
28		FUEL SYSTEMS
28	0	General
28	8	Fuel Sys Control Panel/Controller
28	20	Fuel Distrib/Refueling & Defueling
28	21	Fuel Boost/Transfer/Pumps/Ind
28	30	Fuel Dump System
28	40	Fuel Qty Indication
28	41	Fuel Schedule/Management System
28	43	Fuel Temperature Indication
29		HYDRAULIC POWER
29	0	General
29	8	Hyd. Sys Control Panel/Controller
29	11	ADP/EDP
29	20	Auxiliary/Standby System
29	21	RMP/Aux Pumps
29	30	Hydraulic Indication Systems
29	40	Simulator Hyd Power (HPU)
29	41	Control Valves
29	42	Filters
29	43	Hoses, Tubing, Fittings
29	44	Accumulators
29	45 46	Pumps/Motors
29	46	Control/Monitoring/Warning System
30		ICE:RAIN PROTECTION
30	0	General
30	10	Airfoil Anti-Ice
30	30	Pitot/Static/TAT/AOA Heat

System Code 30 30	Sub Code 40 80	Description Windshield & Windows Ice Detection
31 31 31 31 31 31 31 31 31 31 31	0 10 20 30 31 41 42 43 50 60 61 70	INSTRUMENTS General Instrument Panels Clocks/Chronometer Data Recorders & ULB Data Management (FDAU) Misc Systems Controller Weight & Balance Comp./CGCC Versatile Integrated Avionics (AIU/VIA) Central Warning Systems/ECAM Central Display Sys/ECAM/MCDU Electronic Instrument System/EFIS(Douglas) Monitoring/PSEU
32 32 32 32 32 32 32 32 32 32 32 32 32 3	0 1 10 12 20 30 43 44 45 46 51 60 70	LANDING GEAR General Ground Sensing Main Gear and Doors Body Gear and Doors Nose Gear and Doors Extension & Retraction System Brakes/Cooling System Anti-Skid System Auto Brakes System Brake Temp & Tire Press Mont. Sys Nose/Body Gear Steering System Gear Position Ind/Warning System Tail Skid/Tail Stand
33 33 33 33 33 33 33 33 33	0 1 10 11 30 50 60 61 62	LIGHTING General Lamp Test Flight Comp't/Panel Lighting Master Warning External/Service Lighting Emergency Lighting Simulation Lighting Cockpit Lighting Maintenance Lighting
34 34 34 34 34	0 1 10 11	NAVIGATION General Simulated Nav Aids Alignment Pilot Static Systems Altimeter: Stby Altimeter/Indicated Airspeed

System	Sub		
Code	Code	Description	
34	12	Vertical Speed Indicator	
34	13	RAT/OAT/TRS/SAT/TAS/TAT	
34	14	Airspeed/MACH Indicator/Overspeed Warning	
34	16	Air Data Computing	
34	17	Altitude Alerting	
34	18	Stall Warning/Stick Shaker	
34	19	TAT-EPR Limit/RAT-EPR Limit	
34	21	Compass System	
34	22	Vertical Gyro/Horizon/Attitude	
34	23	Turn and Bank Indicator	
34	24	Standby Compass	
34	25	Standby Attitude/SAI See 34-11	
34	31	Instrument Landing Sys-LOC, G/S, HSI, etc.	
34	35	Marker Beacon System	
34	41	Weather Radar	
34	42	Central Instrument Warning Sys (CIW)	
34	43	INS/IRS Nav	
34	45	Distance Measuring(DME)	
34	48	Radio Altimeter	
34	51	VOR/VHF Navigation	
34	52	Ground Prox Warning/Windshear	
34	53	ADF	
34	55	Traffic & Collision Avoidance (TCAS)	
34	58	Global Nav/Position Sys (GPS/GNS)	
34	61	Performance Data Computer Sys (PDCS)	
34	62	Flight Director Systems	
34	63	Flight Management Computing	
34	73	Electronic Flight Instrument System/EFIS	
35		OXYGEN	
35	0	General	
35	10	Crew Systems	
35	30	Portable Oxygen	
36		PNEUMATIC SYSTEMS	
36	0	General	
36	10	Distribution System/Control	
36	11	Low/High Bleed	
36	12	Pressure Regulation	
36	15	Temp Regulation	
36	20	Manifold Pressure/Temp. Ind	
36	22	Manifold Failure Detection/Ind	
00		NAVA TED NAVA OTE	
38	0	WATER:WASTE	
38	0	General	
45		CENTRAL MAINTENANCE SVS (CMS)	
45 45	0	CENTRAL MAINTENANCE SYS (CMS) General	
45 45	10	Centralized Fault Display System (CFDS)	
45 45	10	On-Board Maintenance Terminal(OMT)	
40	11	On-board Maintenance Terminal(OMT)	

System Code 45	Sub Code 13	Description Pilot Access Terminal (PAT)
46 46	20	ELECTRONIC FLIGHT BAG Electronic Flight Bag
49 49 49 49 49 49 49 49	0 10 17 30 40 50 60 70	AIRBORNE AUX. POWER(APU) General Power Plant Inlet Doors & Actuation Fuel & Control Ignition/Starting Bleed Air System Engine Controls(ECB/ECU & VTN) Indications Oil System
52 52 52 52	0 10 70	DOORS General Crew & Passenger Entry Door Warning Systems
53 53 53 53 53 53 53 53 53 53 53	0 10 11 12 20 30 40 50 60 70	SIMULATOR MOTION General Rams/Legs/Actuators Servo Valves Transducers Base Assembly Accessway/Gantry/Drawbridge Control/Monitoring/Warning System Tuning/Alignment Computer (Reload) Interface
56 56 56 56	0 10 11	WINDOWS General Flight Comp't Windows Cockpit Sliding Windows
73 73 73 73 73 73	0 10 22 30 33	ENGINE FUEL:CONTROL General Fuel Distribution/Supply Auto Fuel Sys/ PMC/TTC/FADEC Indicating Fuel Temp & Heat Fuel Flow/Fuel Used/Fuel Press Ind
74 74 74	0 30	IGNITION SYSTEMS General Ignition Switching

System Code	Sub Code	Description
76		ENGINE CONTROLS
76	0	General
76	10	Power Levers
76	11	Throttle Controls (Cables/Pulleys/Switches)
76	13	Thrust Control Module/TCC
76	15	Fuel Shutoff Levers/Switch
76	20	Emergency Shutdown System/Fire Handles
76	30	Thrust Rev Sys/Actuation/Locking Sys
77		ENGINE INDICATING SYSTEMS
77	0	General
77	10	EPR/PT7, HP Indication
77	11	Alternator Control
77	14	Max Pointer Reset
77	15	N1 RPM Indication
77	16	N2 RPM Indication
77	20	EGT/TGT Indication
77	31	Engine Vibration Indication System
79		ENGINE OIL
79	0	General
79	30	Oil Temp Indication
79	31	Oil Quantity Indication
79	32	Oil Press Indication/Warning
79	34	Oil Differential Pressure Warning
80		SIMULATOR HOST COMPUTER SYSTEM
80	0	General
80	10	Software
80	11	Operating System (MPX,AIX,UNIX)(Reboot)
80	12	Executives/Real Time Control (Reload)
80	13	Real Time Modules
80	14	Utilities
80	15	Diagnostics
80	20	Data Updates
80	21	NDBS/GSD
80	22	INS
80	30	Hardware
80	31	Communications
80	32	Peripherals
80	60	Satellite PCs (Dedicated Function)
81		SIMULATOR ONLY SYSTEMS
81	0	General
81	1	Cables
81	10	Interface/Linkage
81	11	Circuit Board
81	12	Backplane/Buss
81	20	Power Control and Monitoring

System	Sub		
Code	Code	Description	
81	21	Power Supplies	
81	22	400HZ Generation	
81	23	Emergency Power/ Battery Backup	
81	30	Simulated Instruments	
81	40	Simulated A/C Panels	
81	50	Sound/Audio	
85		VISUAL SYSTEM	
85	0	General	
85	1	Ambient Lighting	
85	5	Cables	
85	10	Projection Systems	
85	11	Projector	
85	12	Projection Tubes	
85	13	Mirror and Control Systems	
85	14	Alignment System/AutoCal(DRCU, RAU)	
85	20	Monitor/CRT Systems	
85	21	CRTs	
85	22	Optics	
85	30	Image Generation	
85	31	Computer (Reboot)	
85	32	Circuit Cards	
85	40	Alignments	
85	41	Geometry	
85	42	Color	
85	43	Visibility	
85	50	Models	
85	51	New Model Request	
85	52	Alignment with Nav Aids	
85	53	Airport Lighting/Marking	
85	54	Weather Effects	
99		INSTRUCTOR OPERATING SYSTEM/IF	
99	0	General	
99	10	Computer System	
99	11	Computer (Reboot)	
99	12	Peripherals/Printers	
99	20	Display System	
99	21	Monitors/Display	
99	22	Touchscreen/Input	
99	23	Calibration/Alignment	
99	30	EL Panels/PCU	
99	50	Seats/Movable IOS	
99	60	Control Pages	
99	61	Page Content	
99	62	Page / Malfunction Operation	
99	70	Misc Simulator Controls	

System	Sub	
Code	Code	Description
100		LESSON PLAN
100	0	General
100	10	New Snapshot
100	11	Update Snapshot
100	20	New Scenario
100	21	Update Scenario
100	30	New Lesson
100	31	Update Lesson
100	40	New Menu
100	41	Update Menu