#### 基于 STM32 的硬件 I2C 读取 MPU6050 数据 - 单片机干货 - 中国电子技术论坛 - 最好最受欢迎电子 论坛!

笔记本: STM32学习剪藏资料 创建时间: 2017/9/2 16:35

**URL:** http://bbs.elecfans.com/jishu 485014 1 1.html

## [单片机经验] 基于 STM32 的硬件 I2C 读取 MPU6050 数据

[复制链接]



tyw0403

实习生

## 51单片机 开发板 2000分钟 教学视频 100个 实例代码

马上购买

发表于 2015-5-27 17:43:29

24165 查看

212 回复

只看该作者

本帖最后由 tyw0403 于 2015-6-4 15:06 编辑

根据网上一些资料,调试了两天,终于读取到了MPU6050的六个数据,调试 过程当中也遇到了很多问题,下面在此总结分享一下。

MPU6050其实就是一个 I2C 器件, 里面有很多寄存器 (但是我们用到的只有 几个) , 我们通过读写寄存器来操作这个芯片。所以首要问题就是 STM32 和 MPU6050 的 I2C 通信。

- 1、配置 STM32 (用I2C1: PB6——SCL; PB7——SDA)
  - 1) 时钟 RCC

RCC\_APB2PeriphClockCmd(RCC\_APB2Periph\_GPIOB, ENABLE); RCC APB1PeriphClockCmd(RCC APB1Periph I2C1, ENABLE);

GPIO InitStructure.GPIO Pin = GPIO Pin 6 | GPIO Pin 7; GPIO\_InitStructure.GPIO\_Speed = GPIO\_Speed\_50MHz;

GPIO InitStructure.GPIO Mode = GPIO Mode AF OD; //两个

引脚都加 4.7K 上拉电阻

GPIO\_Init(GPIOB, &GPIO\_InitStructure);

void MPU6050\_Initialize()

存器

{

```
3) I2C 配置
      void I2C Configuration(void)
          I2C InitTypeDef I2C InitStructure;
          I2C_InitStructure.I2C_Mode = I2C_Mode_I2C;
          I2C_InitStructure.I2C_DutyCycle = I2C_DutyCycle_2;
          I2C InitStructure.I2C OwnAddress1 =0xc0; // STM32 的自身地
址,不与从器件相同即可
          I2C_InitStructure.I2C_Ack = I2C_Ack_Enable;
          I2C_InitStructure.I2C_AcknowledgedAddress =
I2C_AcknowledgedAddress_7bit;
          I2C_InitStructure.I2C_ClockSpeed = 100000;
          I2C Init(I2C1, &I2C InitStructure);
          I2C Cmd(I2C1, ENABLE);
      }
至此, STM32 已配置完毕, 其实不是那么难。
2、初始化 MPU6050
```

//初始化过程, 其实就是写 5个寄

```
MPU6050 I2C ByteWrite(0xd0,0x00,MPU6050 RA PWR MGMT 1);
                                                        //
reg107,唤醒,8M内部时钟源
 MPU6050_I2C_ByteWrite(0xd0,0x07,MPU6050_RA_SMPLRT_DIV);
                                                        //
采用频率 1000
         MPU6050 I2C ByteWrite(0xd0,0x06,MPU6050 RA CONFIG);
 MPU6050 I2C ByteWrite(0xd0,0x01,MPU6050 RA ACCEL CONFIG); //
加速度量程 2g
 MPU6050 I2C ByteWrite(0xd0,0x18,MPU6050 RA GYRO CONFIG);
 //角速度量程 2000度/s
    }
注: 0xD0 表示 MPU6050 的地址。我们知道 I2C从器件(在此当然是指
MPU6050) 有 8 位的地址, 前 7 位由 WHO AM I 确定, 第 8 位由 ADO 的电
平决定。WHO AM I 默认值是 0x68H (1101000B) , AD0 接低电平, 所以
MPU6050 的 I2C 地址是 0xD0H (11010000B)。
3、I2C 核心程序 (读/写)
1) 写入寄存器
一次写操作分为几个步骤: 发送开始信号 -> 起始成功? (可能描述的不太准
确) -> 发送 MPU6050 地址、状态 (写) -> 写地址成功? -> 发送 MPU6050
内部某个待写寄存器地址 -> 发送成功? -> 发送要写入的内容 -> 发送成功?
-> 发送结束信号
总结: 先写 MPU6050 地址, 再写 寄存器地址, 最后写 内容, 且每次都要验
证 (应该和应答信号有关)。这就像寄快递一样,先写市县地址,再写街道
地址,最后写门牌号。
再看下面的程序就会更容易理解一些。
void MPU6050 I2C ByteWrite(u8 slaveAddr, u8 pBuffer, u8 writeAddr)
 /* Send START condition */
 I2C_GenerateSTART(I2C1, ENABLE);
                                  //发送开始信号
 /* Test on EV5 and clear it */
 while(!I2C CheckEvent(I2C1, I2C EVENT MASTER MODE SELECT));
 /* Send MPU6050 address for write */
 I2C Send7bitAddress(I2C1, slaveAddr, I2C Direction Transmitter);
// 发送 MPU6050 地址、状态 (写)
 /* Test on EV6 and clear it */
 while(!I2C CheckEvent(I2C1,
I2C_EVENT_MASTER_TRANSMITTER_MODE_SELECTED));
 /* Send the MPU6050's internal address to write to */
 I2C_SendData(I2C1, writeAddr);
                                  //发送 MPU6050内部某个待
写寄存器地址
 /* Test on EV8 and clear it */
 while(!I2C CheckEvent(I2C1,
I2C_EVENT_MASTER_BYTE_TRANSMITTED));
 /* Send the byte to be written */
 I2C SendData(I2C1, pBuffer);
                                  //发送要写入的内容
 /* Test on EV8 and clear it */
 while(!I2C CheckEvent(I2C1,
I2C_EVENT_MASTER_BYTE_TRANSMITTED));
 /* Send STOP condition */
 I2C GenerateSTOP(I2C1, FNARLE):
                                //发送结束信号
```

```
2) 读寄存器
因为 加速度值和角速度值都在寄存器里,所以必须读它才能获得数据。
附上程序
如: MPU6050 I2C BufferRead(0xd0, receive data,
MPU6050_RA_WHO_AM_I, 1); //读 WHO_AM_I 寄存器的值 (0x68)
    void MPU6050 GetRawAccelGyro(s16* AccelGyro)
                                                   //读加速度值
和 角速度值
   {
         u8 tmpBuffer[14],i;
         MPU6050 I2C BufferRead(0xd0, tmpBuffer,
MPU6050 RA ACCEL XOUT H, 14);
         /* Get acceleration */
         for(i=0; i<3; i++)
        AccelGyro=((s16)((u16)tmpBuffer[2*i] << 8) +
tmpBuffer[2*i+1]);
  /* Get Angular rate */
        for(i=4; i<7; i++)
                                                  //在此跳过温度
寄存器,不需要温度值
        AccelGyro[i-1]=((s16)((u16)tmpBuffer[2*i] << 8) +
tmpBuffer[2*i+1]);
    }
注:
#define MPU6050_RA_ACCEL_XOUT_H
                                    0x3B
#define MPU6050_RA_ACCEL_XOUT_L
                                    0x3C
#define MPU6050_RA_ACCEL_YOUT_H
                                    0x3D
#define MPU6050_RA_ACCEL_YOUT_L
                                    0x3E
#define MPU6050_RA_ACCEL_ZOUT_H
                                    0x3F
#define MPU6050_RA_ACCEL_ZOUT_L
                                    0x40
#define MPU6050 RA TEMP OUT H
                                    0x41
#define MPU6050_RA_TEMP_OUT_L
                                    0x42
#define MPU6050_RA_GYRO_XOUT_H
                                    0x43
#define MPU6050_RA_GYRO_XOUT_L
                                    0x44
#define MPU6050_RA_GYRO_YOUT_H
                                    0x45
#define MPU6050 RA GYRO YOUT L
                                    0x46
#define MPU6050_RA_GYRO_ZOUT_H
                                    0x47
#define MPU6050 RA GYRO ZOUT L
                                    0x48
I2C 读核心程序:
void MPU6050_I2C_BufferRead(u8 slaveAddr, u8* pBuffer, u8 readAddr,
u16 NumByteToRead)
{
 /* While the bus is busy */
 while(I2C_GetFlagStatus(I2C1, I2C_FLAG_BUSY));
 /* Send START condition */
 I2C_GenerateSTART(I2C1, ENABLE);
 /* Test on EV5 and clear it */
 while(!I2C_CheckEvent(I2C1, I2C_EVENT_MASTER_MODE_SELECT));
 /* Send MPU6050 address for write */
 I2C_Send7bitAddress(I2C1, slaveAddr, I2C_Direction_Transmitter);
 /* Test on EV6 and clear it */
 while(!I2C_CheckEvent(I2C1,
I2C_EVENT_MASTER_TRANSMITTER_MODE_SELECTED));
 /* Clear FV6 hv setting again the PF hit */
```

```
I2C Cmd(I2C1, ENABLE);
 /* Send the MPU6050's internal address to write to */
 I2C_SendData(I2C1, readAddr);
 /* Test on EV8 and clear it */
 while(!I2C CheckEvent(I2C1,
I2C_EVENT_MASTER_BYTE_TRANSMITTED));
/* Send STRAT condition a second time */
 I2C GenerateSTART(I2C1, ENABLE);
 /* Test on EV5 and clear it */
 while(!I2C_CheckEvent(I2C1, I2C_EVENT_MASTER_MODE_SELECT));
 /* Send MPU6050 address for read */
 I2C_Send7bitAddress(I2C1, slaveAddr, I2C_Direction_Receiver);
 /* Test on EV6 and clear it */
 while(!I2C_CheckEvent(I2C1,
I2C_EVENT_MASTER_RECEIVER_MODE_SELECTED));
 /* While there is data to be read */
 while(NumByteToRead)
  if(NumByteToRead == 1)
   /* Disable Acknowledgement */
   I2C_AcknowledgeConfig(I2C1, DISABLE);
   /* Send STOP Condition */
   I2C_GenerateSTOP(I2C1, ENABLE);
  /* Test on EV7 and clear it */
  if(I2C_CheckEvent(I2C1, I2C_EVENT_MASTER_BYTE_RECEIVED))
   /* Read a byte from the MPU6050 */
   *pBuffer = I2C_ReceiveData(I2C1);
   /* Point to the next location where the byte read will be saved */
   pBuffer++;
   /* Decrement the read bytes counter */
   NumByteToRead--;
 /* Enable Acknowledgement to be ready for another reception */
 I2C_AcknowledgeConfig(I2C1, ENABLE);
```

最后, 把六个值 printf 出来就行。

### 最后附上程序一份!



# MPU6050 I2C读取数据 -精简版.z

4.47 MB, 下载次数: 10871, 下载

积分: 积分 -1 分

收藏42

举报 标签: stm32 I2C MPU6050 stm32 stm32

,	
	相关帖子
	□ 实习工作小结第二十九天 □ 广告贴 □ 求助 □ 实习工作小结第二十八天 □ stm32 i2c通信的MLX90614测温 □ 实习工作小结第二十七天 □ MPU6050移植编译错误
	一 1011 000301夕恒端片旧读

楼主热帖
□ 谈一谈 MPU6050 姿态融合
□ 时序图绘制软件 —— TimeGen (附件含有软件 + 教
基于STM32F103RCT6的无源蜂鸣器音乐播放(生日快
☐ 基于 stm32f103rct6 和 lcd1602 的闹钟程序



👊 【点击赢现金大奖】100套STM32 开发套件免费领! 重磅含金量证书等你拿!

发表于 2015-7-19 16:15:47 22<sup>±</sup>

楼主讲的很仔细,谢谢楼主,看了之后明白了很多。。。。。。

