

FieldTalk™ diagslave

Read Me Notes

Revision 2.12, 2012-07-19

This Read Me file contains last-minute product information for the FieldTalk $^{\text{TM}}$ diagslave utility. diagslave is a command line based Modbus slave simulator and test utility. It is free software.

Files part of the package

```
README.pdf
These Read Me notes.

LICENSE-FREE, LICENSE-FREE.pdf
License containing the Terms & Conditions of use for this free software.

linux/diagslave
Linux x86 binary

qnx6/diagslave
QNX 6 x86 binary

win32/diagslave.exe
Windows command line binary
```

Source code for illustration purposes. Requires FieldTalk Modbus Slave C++ Library to compile.

Usage

```
Usage: diagslave [OPTIONS] [SERIALPORT]
Arguments:
serialport
             Serial port when using Modbus ASCII or Modbus RTU protocol
             COM1, COM2 ...
                                          on Windows
             /dev/ttyS0, /dev/ttyS1 ...
                                          on Linux
             /dev/ser1, /dev/ser2 ...
                                         on QNX
General options:
-m ascii Modbus ASCII protocol
-m tcp
-o #
             Modbus RTU protocol (default)
             MODBUS/TCP protocol
             Master activity time-out in seconds (1.0 - 100, 3 s is default)
             Connection time-out in seconds (1.0 - 3600, 60 s is default)
-c #
-a #
             Slave address (1-255 for RTU/ASCII, 0-255 for TCP)
Options for MODBUS/TCP:
-p #
             TCP port number (502 is default)
Options for Modbus ASCII and Modbus RTU:
             Baudrate (e.g. 9600, 19200, ...) (19200 is default)
-b #
-d #
             Databits (7 or 8 for ASCII protocol, 8 for RTU)
-s #
             Stopbits (1 or 2, 1 is default)
-p none
             No parity
-p even
             Even parity (default)
-p odd
             Odd parity
```

README 1

-4 # RS-485 mode, RTS on while transmitting and another # ms after

Release history

Version 2.12 (2012-07-19)

- RTU/ASCII: Added RS-485 mode for Win32, QNX and Linux platforms.
- COMn syntax can now also be used for COM port number >= 10

Version 2.11 (2011-03-05)

• Protocol is now auto-detected as RTU or TCP depending on value of first parameter

Version 2.10 (2010-03-31)

• Added connection time-out, changed -t to -o for activity time-out.

Version 2.9 (2009-11-16)

• Default baudrate is now 19200 as per Modbus standard.

Version 2.8 (2009-10-26)

• Using the -d and -s command line parameters returned an error message in earlier releases.

Version 2.7 (2009-10-20)

• First release as standalone application.

Copyright (c) 2002-2011 proconX Pty Ltd. All rights reserved.

Email: mail@modbusdriver.com [mailto:mail@modbusdriver.com]

Please refer to file LICENSE-FREE for license and distribution terms.

THIS SOFTWARE IS PROVIDED BY PROCONX AND CONTRIBUTORS "AS IS" AND ANY EXPRESS OR IMPLIED WARRANTIES, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE ARE DISCLAIMED. IN NO EVENT SHALL PROCONX OR CONTRIBUTORS BE LIABLE FOR ANY DIRECT, INDIRECT, INCIDENTAL, SPECIAL, EXEMPLARY, OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, PROCUREMENT OF SUBSTITUTE GOODS OR SERVICES; LOSS OF USE, DATA, OR PROFITS; OR BUSINESS INTERRUPTION) HOWEVER CAUSED AND ON ANY THEORY OF LIABILITY, WHETHER IN CONTRACT, STRICT LIABILITY, OR TORT (INCLUDING NEGLIGENCE OR OTHERWISE) ARISING IN ANY WAY OUT OF THE USE OF THIS SOFTWARE, EVEN IF ADVISED OF THE POSSIBILITY OF SUCH DAMAGE.

README 2