




Sheet: /LS/
File: LS4.kicad_sch

Title:

Size: A4


Date:

KiCad E.D.A. 8.0.9

Rev:

Id: 3/6

Remove R20–R22, R26–R28, and install Q7–Q12 for use with dumb coils



Sheet: /Ignition/
File: IGN6.kicad_sch

Title:


Size: A4

Date:


KiCad E.D.A. 8.0.9

Rev:

Id: 5/6



Sheet: /LSH/ File: LS_H.kicad_sch		
Title:		
Size: A4	Date:	Rev:
KiCad E.D.A. 8.0.9	Id: 6/6	



Sheet: /Injector/
File: INJ6.kicad_sch

Title:


Size: A4

Date:

KiCad E.D.A. 8.0.9

Rev:

Id: 6/6



NUP2105L is optional, used for protection

Sheet: /EGT/
File: egt.kicad_sch

Title:

Size: A4

Date:

KiCad E.D.A. 8.0.9

Rev:

Id: 9/6