ITDB02_tinyFAT - Add-on library to integrate ITDB02_Graph and tinyFAT

Copyright (C)2011 Henning Karlsen. All right reserved

Basic functionality of this library are based on the demo-code provided by ITead studio. You can find the latest version of the library at http://www.henningkarlsen.com/electronics

This library has been made especially for the 2.4" TFT LCD Screen Modules: ITDB02-2.4D by ITead studio. This library has been designed to use 8bit mode, so it will not work with the 3.2" Module.

If you make any modifications or improvements to the code, I would appreciate that you share the code with me so that I might include it in the next release. I can be contacted through http://www.henningkarlsen.com/electronics/contact.php

This library is free software; you can redistribute it and/or modify it under the terms of the GNU Lesser General Public License as published by the Free Software Foundation; either version 2.1 of the License, or (at your option) any later version.

This library is distributed in the hope that it will be useful, but WITHOUT ANY WARRANTY; without even the implied warranty of MERCHANTABILITY or FITNESS FOR A PARTICULAR PURPOSE. See the GNU Lesser General Public License for more details.

You should have received a copy of the GNU Lesser General Public License along with this library; if not, write to the Free Software Foundation, Inc., 51 Franklin St, Fifth Floor, Boston, MA 02110-1301 USA

Version:	1.0	Apr 19 2011	•	initial release
----------	-----	-------------	---	-----------------

IMPORTANT:

If you are upgrading from $ITDB02_Graph\ v4.01$ or lower there are a couple of things you need to change.

- You must include "tinyFAT.h", "ITDB02_Graph" and "ITDB02_tinyFAT" in your sketch
- All references to the class ITDB02 must be changed to ITDB02tf

No other changes should be necessary. All functions available to the ITDB02 class is also available in the ITDB02tf class. Please see the $ITDB02_Graph$ documentation for a description of those functions.

Functions:

```
ITDB02tf(RS, WR, CS, RST[, Model]);

The main class of the interface.

Parameters:

RS: Arduino pin for Register Select
WR: Arduino pin for Write
CS: Arduino pin for Chip Select
RST: Arduino pin for Reset
Model: <optional>
ITDB24 (default)
ITDB24b

Usage:

ITDB02tf myGLCD(19,18,17,16); // Start an instance of the ITDB02 class
```