Generic IoT Device User Manual

Table of Contents

- 1. Introduction
- 2. Features
- 3. Network Setup
- 4. Telnet Access

1. Introduction

Thanks for purchasing Generic IoT Device. In this manual you will find the necessary information to configure your new device.

2. Features

- Remote access to keep track of the status
- Notifications to your phone
- Integration with already existing IoT devices

3. Network Setup

- Wi-Fi Setup:
 - Open the Generic app and navigate to 'Add Device.'
 - Select 'Wi-Fi Setup' and follow the prompts to connect the device to your home network.
- Ethernet Setup:
 - o Connect the Ethernet cable to the device and your router.
 - The device will automatically configure the network settings.

4. Telnet Access

If you want to configure the device manually it also supports telnet.

Telnet Credentials:

Username: adminPassword: admin1234

Steps to Access Telnet:

- 1. Open a terminal on your machine
- 2. Type telnet [IP address of your device] and press Enter.
- 3. When prompted, enter the username admin and password admin1234.
- 4. You now have access to the Telnet interface for advanced configuration.

Note: Please change the telnet credentials, otherwise your device will be vulnerable to malware.