JEREMY'S ARDUINO TUTORIAL SERIES

Sponsored by element14

EPISODE 10: INTERRUPTS AND HARDWARE DEBOUNCING

WATCH THIS EPISODE

Youtube: http://www.youtube.com/watch?v=CRJUdf5TTQQ

PARTS LIST

- 1. Arduino Uno: http://us.element-14.com/arduino/a000046/arduino-uno-board/dp/13T9285
- 2. USB Cable: http://us.element-14.com/jsp/search/productdetail.jsp?SKU=73H0884
- 3. Arduino Software: http://arduino.cc/en/Main/Software
- 4. Breadboard: http://us.element-14.com/jsp/search/productdetail.jsp?SKU=17C6965
- 5. LEDs: http://us.element-14.com/jsp/search/productdetail.jsp?SKU=30K0645
- 6. 150 ohm Resistor: http://us.element-14.com/multicomp/mcf-0-25w-150r/resistor-carbon-film-150ohm-250mw/dp/38K0339
- 7. Pushbutton: http://us.element-14.com/c-k/ksl1m411-lft/switch-tactile-spst-no-50ma-thd/dp/88K5321
- 8. Jumper Kit: http://us.element-14.com/3m/923351-i/pcb-accessories/dp/65F2290
- 9. IR Distance Sensor: http://us.element-14.com/sharp/gp20a41sk0f/dp/14N9318
- 10. Inverting Schmitt Trigger: http://us.element-14.com/stmicroelectronics/m74hc14b1r/ic-hex-inverter-schmitt-trigger/dp/89K0862
- 11. 10k ohm Resistor: http://us.element-14.com/multicomp/mccfr0w4j0103a50/resistor-carbon-film-10kohm-250mw/dp/58K5002
- 12. 10uF Capacitor: http://us.element-14.com/multicomp/mcgpr100v106m6-3x11/capacitor-alum-elect-10uf-100v/dp/70K9661