```
LidarInfolf
+ ~LidarInfolf()
+ getseries()
+ getspeed()
+ getname()
+ getfwinfo()
+ getstate()
+ getsamplerate()
+ getconfiguration()
+ getconninfo()
       Lidarlf
    + ~Lidarlf()
    + setup()
       Lidar
# series
# baud
# initscans
# seriallf
# scans
+ setup()
+ getseries()
+ getspeed()
+ getname()
+ getfwinfo()
+ getstate()
+ getsamplerate()
+ getconfiguration()
+ getconninfo()
+ watchangle()
+ runscan()
+ stopscan()
+ getscaninfo()
Lidar()
getseries()
getpacket()
getscan()
```