

Part I

Explain the rationale behind MIPS designers' decision not to provide a NOT instruction in the MIPS ISA in 2 parts

1. The NOT instruction isn't needed because there is already a NOR instruction that can do the same thing
2. `nor $t0, $t1, $zero`