

How to use a paper shredder to cut paper into stripes

How to use a paper shredder to cut paper into stripes

Target user persona

Purpose

Paper Shredder

Safety Precautions

Features

Parts and Function

Instructions

Maintenance

Specifications

Target user persona

Lucy is the HR Assistant working in an Internet company in China.

- Educational background: She is a graduate with a bachelor's degree in Human Resources.
- Cultural experience: She is a native Chinese speaker.
- English competency: She can read and write in English.
- Work experience: She is a new grad with limited work experience.
- Responsibilities: She is responsible for all stages of the recruitment lifecycle.
- Personal preference: She reads documents fast but doesn't like long and complex instructions.

Purpose

Lucy has worked in the company for three months and accumulated many unnecessary documents with personal and confidential information. But she has trouble using the paper shredder and needs to read the instructions to destroy all these documents.

She wishes the instruction could be short and easy to read with all the necessary information and tips.

Paper Shredder

A paper shredder is a machine that can cut paper, credit cards, or CDs into strips or confetti-like pieces. It has two main components, a "paper cutter" and an "electric motor." Belts and gears connect the two parts. Strip-cut shredders may use rotating knives to cut the paper, while cross-cut shredders may use two sets of teeth that rotate in opposite directions to get a much smaller

particle. When the paper(or other objects) touches the entry area, sensor activities, the knife turn and pull the paper into the waste bin until there is nothing to cut.

Safety Precautions

Please do not touch the plug when your hands are wet.

- Please do not touch the plug when your hands are wet.
- Please do not wash the machine and prevent water from flowing into it.
- Please do not put foreign objectives while the engine is operating.
- Please do not cover clothes on the device.
- Please do not use the machine next to the curtains.
- Keep children away from the machine.

Features

- High-security level with German standard.
- Smash paper into 4 x 25 mm pieces, as small as seven rice grains.
- Keep working for five minutes to save your time.
- Cut up to five pieces of A4(70 g) paper at a time with sharp knife steels.

Easy to move with a bodyweight of only 4.0 KG.

The internal noise reduction system ensures you a quiet working environment.


High-performance motor provides you a sustainable power.

High-capacity waste bin and easy to check through the window.

Auto-reverse when overload and overheat protection warning.

- Auto switch from FWD to REV to smash your waste documents.
- Ease for you to use with simple operation buttons.

Parts and Function



Instructions

1. Connect the power plug and the power indicator is on, the whole machine is in standby mode.
2. Turn it on by pressing the power switch on the side of the machine.
3. Prepare the paper, credit cards, or CDs you don't need. Ensure that you have removed the paper clip and staples to ensure a smooth operation.
4. Put the paper into the paper entry and credit cards or CDs into the CD/credit card entry.Adjust to the maximum amount so that the working condition is optimal.
5. Wait until the shredder finishes to cut.
6. After done, press the power switch and turn off the machine. Pull out the waste bin and discard the pieces.

Maintenance

- Make sure that you placed the shredder on a flat surface and has locked the casters.
- Make sure to place the machine in a dry and safe area.
- Turn off the power and pull out the plug before the cleaning and maintenance.
- Keep the machine's surface clean to prevent color change.
- Do periodic lubrication checks on the gears and blades.
- Check the edges on the device and connect the after-sale department to replace them when they are dull or blunt.
- Keep the machine from the magnet.

Specifications

Product Information	
Item	0000
Type	Office paper shredder
Name	Small paper shredder
Shred capacity	A4(70 g) 5 sheet paper,1 credit card,1 CD at a time
Shred size	4x25mm
Entry width	220 mm(A4)
Shred speed	2m/min
Dimension(mm)\Net weight	350x320x200mm\4.0 KG
Basket Volume	15L
Power rating	80 W
Voltage rating	AC 220 V 50 HZ

That is the end of the instruction, thanks for your reading.