# DaVinci Configurator Classic and DaVinci Developer Classic
## Minimum Required Tool Version AUTOSAR Classic Schema

| AUTOSAR Classic Schema | DaVinci Configurator Classic | DaVinci Developer Classic |
|---|---|---|
| **Release** | **Release** | **Release** |
| R23-11 (AUTOSAR_00052.xsd) | DaVinci Configurator Classic 5.29 | DaVinci Developer Classic 4.14 |
| R22-11 (AUTOSAR_00051.xsd) | DaVinci Configurator Classic 5.27 | DaVinci Developer Classic 4.12 |
| R21-11 (AUTOSAR_00050.xsd - AR Classic 4.7.0) | DaVinci Configurator Classic 5.25 | DaVinci Developer Classic 4.10 |
| R20-11 (AUTOSAR_00049.xsd - AR Classic 4.6.0) | DaVinci Configurator Pro 5.23 | DaVinci Developer 4.8 |
| R19-11 (AUTOSAR_00048.xsd - AR Classic 4.5.0) | DaVinci Configurator Pro 5.22 | DaVinci Developer 4.6 |
| R19-03 (AUTOSAR_00047.xsd - AR Classic 4.4.0) | DaVinci Configurator Pro 5.20 | DaVinci Developer 4.4 |
| R18-10 (AUTOSAR_00046.xsd - AR Classic 4.4.0) | DaVinci Configurator Pro 5.19 | DaVinci Developer 4.4 |
| R18-03 (AUTOSAR_00045.xsd - AR Classic 4.3.1) | DaVinci Configurator Pro 5.18 | DaVinci Developer 4.2 |
| R17-10 (AUTOSAR_00044.xsd - AR Classic 4.3.1) | DaVinci Configurator Pro 5.17 | DaVinci Developer 4.2<br>DaVinci Developer 3.13 (SP6) |
| R17-10 (AUTOSAR_00043.xsd - AR Classic 4.3.0) | DaVinci Configurator Pro 5.17 | DaVinci Developer 3.13 (SP3) |
| R4.3.0 (AUTOSAR_4-3-0.xsd) | DaVinci Configurator Pro 5.15 | DaVinci Developer 3.13 (SP3) |
| R4.2.2 (AUTOSAR_4-2-2.xsd) | DaVinci Configurator Pro 5.11 | DaVinci Developer 3.12 |
| R4.2.1 (AUTOSAR_4-2-1.xsd) | DaVinci Configurator Pro 5.8 (SP2) | DaVinci Developer 3.9 (SP1) |
| R4.1.3 (AUTOSAR_4-1-3.xsd) | DaVinci Configurator Pro 5.7 | DaVinci Developer 3.7 (SP3) |
| R4.1.2 (AUTOSAR_4-1-2.xsd) | DaVinci Configurator Pro 5.6 (SP1) | DaVinci Developer 3.7 |
| R4.1.1 (AUTOSAR_4-1-1.xsd) | DaVinci Configurator Pro 5.5 | DaVinci Developer 3.7 |
| R4.0.3 (AUTOSAR_4-0-3.xsd) | DaVinci Configurator Pro 5.2 | DaVinci Developer 3.3 (SP3) |
| R4.0.2 (AUTOSAR_4-0-2.xsd) | DaVinci Configurator Pro 5.0.1 | DaVinci Developer 3.3 (SP1) |
| R4.0.1 (AUTOSAR_4-0-1.xsd) | DaVinci Configurator Pro 5.0.1 | DaVinci Developer 3.3 (SP1) |

For DaVinci release roadmap please visit
https://portal.vector.com/de/web/davinci/release-roadmap

You will find more useful know-how and information on tools, embedded software and services at **www.vector.com**.