

EK-TM4C1294XL-BOOSTXL-SENSHUB Firmware Development Package

USER'S GUIDE

Copyright

Copyright © 2013-2014 Texas Instruments Incorporated. All rights reserved. Tiva and TivaWare are trademarks of Texas Instruments Instruments. ARM and Thumb are registered trademarks and Cortex is a trademark of ARM Limited. Other names and brands may be claimed as the property of others.

APlease be aware that an important notice concerning availability, standard warranty, and use in critical applications of Texas Instruments semiconductor products and disclaimers thereto appears at the end of this document.

Texas Instruments 108 Wild Basin, Suite 350 Austin, TX 78746 www.ti.com/tiva-c







Revision Information

This is version 2.1.0.12573 of this document, last updated on February 07, 2014.

Table of Contents

Cop	yright	2
Revi	ision Information	2
1	Introduction	5
2	Example Applications	7
2.1	Nine Axis Sensor Fusion with the MPU9150 and Complimentary-Filtered DCM (compdcm_mpu9150) Humidity Measurement with the SHT21 (humidity_sht21)	7
2.2	Humidity Measurement with the SHT21 (humidity_sht21)	7
2.3	Light Measurement with the ISL29023 (light_isl29023)	8
2.4	Pressure Measurement with the BMP180 (pressure_bmp180)	8
2.5	SensHub Internet of Things Example (senshub_iot)	8
2.6	Temperature Measurement with the TMP006 (temperature_tmp006)	S
IMP	ORTANT NOTICE	C

1 Introduction

The Texas Instruments® Tiva™ EK-TM4C1294XL-BOOSTXL-SENSHUB evaluation board (Tiva C Series TM4C1294 Connected LaunchPad) is a low cost platform that can be used for software development and prototyping a hardware design. A variety of BoosterPacks are available to quickly extend the LaunchPad's features.

The EK-TM4C1294XL-BOOSTXL-SENSHUB includes a Tiva ARM® Cortex™-M4-based microcontroller and the following features:

- TivaTM TM4C1294NCPDT microcontroller
- Ethernet connector
- USB OTG connector
- 2 user buttons
- 4 User LEDs
- 2 booster pack connectors
- On-board In-Circuit Debug Interface (ICDI)
- Power supply option from USB ICDI connection, USB OTG connection or external power connection
- Shunt jumper for microcontroller current consumption measurement

This document describes the example applications that are provided for the EK-TM4C1294XL when paired with the BOOSTXL-SENSHUB BoosterPack. This BoosterPack provides a variety of motion and environmental sensors. It also provides an EM expansion option for attachement of additional peripherals such as the CC2533EMK or CC4000EMK. These examples utilize the TivaWare for C Series Sensor Library to extract and process information from the BOOSTXL-SENSHUB.

2 Example Applications

The example applications show how to utilize features of the EK-TM4C1294XL development board. Examples are included to show how to use many of the general features of the Tiva microcontroller, as well as the feature that are unique to this development board.

A number of drivers are provided to make it easier to use the features of the EK-TM4C1294XL. These drivers also contain low-level code that make use of the TivaWare peripheral driver library and utilities.

There is an IAR workspace file (ek-tm4c1294x1-boostx1-senshub.eww) that contains the peripheral driver library project, along with all of the board example projects, in a single, easy-to-use workspace for use with Embedded Workbench

There is a Keil multi-project workspace file (ek-tm4c1294xl-boostxl-senshub.mpw) that contains the peripheral driver library project, along with all of the board example projects, in a single, easy-to-use workspace for use with uVision.

All of these examples reside in the examples/boards/ek-tm4c1294xl-boostxl-senshub subdirectory of the firmware development package source distribution.

2.1 Nine Axis Sensor Fusion with the MPU9150 and Complimentary-Filtered DCM (compdcm_mpu9150)

This example demonstrates the basic use of the Sensor Library, TM4C1294 LaunchPad and SensHub BoosterPack to obtain nine axis motion measurements from the MPU9150. The example fuses the nine axis measurements into a set of Euler angles: roll, pitch and yaw. It also produces the rotation quaternions. The fusion mechanism demonstrated is a complimentary-filtered direct cosine matrix (DCM) algorithm. The algorithm is provided as part of the Sensor Library.

This example requires that the BOOSTXL-SENSHUB be installed on BoosterPack 1 interface headers. See code comments for instructions on how to use BoosterPack 2 interface.

Connect a serial terminal program to the LaunchPad's ICDI virtual serial port at 115,200 baud. Use eight bits per byte, no parity and one stop bit. The raw sensor measurements, Euler angles and quaternions are printed to the terminal. An LED begins to blink at 1Hz after initialization is completed and the example application is running.

2.2 Humidity Measurement with the SHT21 (humidity_sht21)

This example demonstrates the basic use of the Sensoror Library, TM4C1294XL LaunchPad and SensHub BoosterPack to obtain temperature and relative humidity of the environment using the Sensirion SHT21 sensor.

This example requires that the SensHub BoosterPack is installed on BoosterPack 1 interface headers on the LaunchPad. See the code comments for information on porting this to use BoosterPack 2.

Connect a serial terminal program to the LaunchPad's ICDI virtual serial port at 115,200 baud. Use eight bits per byte, no parity and one stop bit. The humidity and temperature as measured by the SHT21 is printed to the terminal. An LED will blink to indicate the application is running.

2.3 Light Measurement with the ISL29023 (light_isl29023)

This example demonstrates the basic use of the Sensor Library, TM4C1294 Connected Launch-Pad and the SensHub BoosterPack to obtain ambient and infrared light measurements with the ISL29023 sensor.

The SensHub BoosterPack must be installed on BoosterPack 1 interface. See code comments for changes needed to use BoosterPack 2 interface.

Connect a serial terminal program to the LaunchPad's ICDI virtual serial port at 115,200 baud. Use eight bits per byte, no parity and one stop bit. The raw sensor measurements are printed to the terminal. An LED blinks at 1Hz once the initialization is complete and the example is running.

The code automatically adjusts the dynamic range of the sensor when the intensity reaches a min or max threshold within the current range setting.

2.4 Pressure Measurement with the BMP180 (pressure_bmp180)

This example demonstrates the basic use of the Sensor Library, the EK-TM4C1294XL LaunchPad, and the SensHub BoosterPack to obtain air pressure and temperature measurements with the BMP180 sensor.

SensHub BoosterPack (BOOSTXL-SENSHUB) must be installed on BoosterPack 1 interface headers.

Instructions for use of SensorHub on BoosterPack 2 headers are in the code comments.

Connect a serial terminal program to the LaunchPad's ICDI virtual serial port at 115,200 baud. Use eight bits per byte, no parity and one stop bit. The raw sensor measurements are printed to the terminal. The LED blinks at 1 Hz once the initialization is complete and the example is running.

2.5 SensHub Internet of Things Example (senshub_iot)

This application uses FreeRTOS to manage multiple sensor tasks and aggregate sensor data to be published to a cloud server. The senshub_iot.c file contains the main function and perform task init before handing control over to the FreeRTOS scheduler.

The tasks and their responsibilities are as follows:

- cloud_task.c is a manager of the cloud interface. It gathers the sensor data and builds it into a packet for transmission to the cloud.
- command_task.c is a manager of the UART virtual com port connection to a local PC. This interface allows advanced commands and data.

- isl29023_task.c is a task to manage the interface to the isl29023 light sensor. It collects data from the sensor and makes it available to other tasks.
- tmp006_task.c is a task that manages the tmp006 temperature sensor. It gathers data from the temperature sensor and makes it available to other tasks.
- bmp180_task.c is a task that manages the bmp180 pressure sensor. It gathers data from the sensor and makes it available to other tasks.
- compdcm_task.c is a task that manages data from the MPU9150. It performs complimentary direct cosine matrix filter on the data to determine roll, pitch and yaw as well as quaternions. This data is made available to other tasks.
- sht21_task.c is a task that manages the SHT21 humidity and temperature sensor. It collects data from the sensor and makes it available to other tasks.

In addition to the tasks, this application also uses the following FreeRTOS resources:

- Queues enable information transfer between tasks.
- Mutex Semaphores guard resources such as the UART from access by multiple tasks at the same time.
- Binary Semaphores synchronize events between interrupts and task contexts.
- A FreeRTOS Delay to put the tasks in blocked state when they have nothing to do.
- A Software timer to regulate the timing of cloud sync events.
- The FreeRTOS run time stats feature to show CPU usage of each task at run time.

For additional details on FreeRTOS, refer to the FreeRTOS web page at: http://www.freertos.org/

2.6 Temperature Measurement with the TMP006 (temperature_tmp006)

This example demonstrates the basic use of the Sensor Library, TM4C1294 Connected LaunchPad and the SensHub BoosterPack to obtain ambient and object temperature measurements with the Texas Instruments TMP006 sensor.

SensHub BoosterPack (BOOSTXL-SENSHUB) Must be installed on BoosterPack 1 interface headers.

Connect a serial terminal program to the LaunchPad's ICDI virtual serial port at 115,200 baud. Use eight bits per byte, no parity and one stop bit. The raw sensor measurements are printed to the terminal. An LED blinks at 1Hz once the initialization is complete and the example is running.

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have not been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

rnd	uci	te

Wireless Connectivity

Audio www.ti.com/audio **Amplifiers** amplifier.ti.com **Data Converters** dataconverter.ti.com **DLP® Products** www.dlp.com DSP dsp.ti.com Clocks and Timers www.ti.com/clocks Interface interface.ti.com Logic logic.ti.com Power Mgmt power.ti.com Microcontrollers microcontroller.ti.com www.ti-rfid.com **OMAP Applications Processors** www.ti.com/omap

Applications

Automotive and Transportation www.ti.com/automotive Communications and Telecom www.ti.com/communications Computers and Peripherals www.ti.com/computers Consumer Electronics www.ti.com/consumer-apps **Energy and Lighting** www.ti.com/energy Industrial www.ti.com/industrial Medical www.ti.com/medical Security www.ti.com/security Space, Avionics and Defense www.ti.com/space-avionics-defense Video and Imaging www.ti.com/video

TI E2E Community

e2e.ti.com

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2013-2014, Texas Instruments Incorporated

www.ti.com/wirelessconnectivity