CS 61C Spring 2022

RISC-V Pipelining and Hazards

Discussion 8

1 Pre-Check

This section is designed as a conceptual check for you to determine if you conceptually understand and have any misconceptions about this topic. Please answer true/false to the following questions, and include an explanation:

- 1.1 Pipelining the CPU datapath results in instructions being executed with higher latency and higher throughput.
- 1.2 Without forwarding, data hazards will usually result in 3 stalls.
- 1.3 All data hazards can be resolved with forwarding.
- 1.4 Stalling is the only way to resolve control hazards.

2 Pipelining Registers

In order to pipeline, we add registers between the five datapath stages. Label each of the five stages (IF, ID, EX, MEM, and WB) on the diagram attached at the end of the worksheet.

- 2.1 What is the purpose of the new registers?
- Why do we add +4 to the PC again in the memory stage?

3 Performance Analysis

Register clk-to-q 30 psBranch comp. 75 psMemory write 200 psRegister setup 20 psALU 200 psRegFile read 150 psMux 25 psMemory read 250 psRegFile setup 20 ps

3.1 With the delays provided above for each of the datapath components, what would be the fastest possible clock time for a single cycle datapath?

3.2 What is the fastest possible clock time for a pipelined datapath?

3.3 What is the speedup from the single cycle datapath to the pipelined datapath? Why is the speedup less than 5?

4 Hazards

One of the costs of pipelining is that it introduces three types of pipeline hazards: structural hazards, data hazards, and control hazards.

Structural Hazards

Structural hazards occur when more than one instruction needs to use the same datapath resource at the same time. There are two main causes of structural hazards:

Register File The register file is accessed both during ID, when it is read, and during WB, when it is written to. We can solve this by having separate read and write ports. To account for reads and writes to the same register, processors usually write to the register during the first half of the clock cycle, and read from it during in the second half. This is also known as double pumping.

Memory Memory is accessed for both instructions and data. Having a separate instruction memory (abbreviated IMEM) and data memory (abbreviated DMEM) solves this hazard.

Something to remember about structural hazards is that they can always be resolved by adding more hardware.

Data Hazards

Data hazards are caused by data dependencies between instructions. In CS 61C, where we will always assume that instructions are always going through the processor in order, we see data hazards when an instruction **reads** a register before a previous instruction has finished **writing** to that register.

Control Hazards

Control hazards are caused by **jump and branch instructions**, because for all jumps and some branches, the next PC is not PC + 4, but the result of the computation completed in the EX stage. We could stall the pipeline for control hazards, but this decreases performance.

Forwarding

Most data hazards can be resolved by forwarding, which is when the result of the EX or MEM stage is sent to the EX stage for a following instruction to use.

4.1 Look for data hazards in the code below, and figure out how forwarding could be used to solve them.

| Instruction | C1 | C2 | C3 | C4 | C5 | C6 | C7 |
|--------------------|----|----|----|-----|-----|-----|----|
| 1. addi t0, a0, -1 | IF | ID | EX | MEM | WB | | |
| 2. and s2, t0, a0 | | IF | ID | EX | MEM | WB | |
| 3. sltiu a0, t0, 5 | | | IF | ID | EX | MEM | WB |

4.2 Imagine you are a hardware designer working on a CPU's forwarding control logic. How many instructions after the addi instruction could be affected by data hazards created by this addi instruction?

Stalls

4.3 Look for data hazards in the code below. One of them cannot be solved with forwarding—why? What can we do to solve this hazard?

| Instruction | C1 | C2 | C3 | C4 | C5 | C6 | C7 | C8 |
|-------------------|----|----|----|-----|-----|-----|-----|----|
| 1. addi s0, s0, 1 | IF | ID | EX | MEM | WB | | | |
| 2. addi t0, t0, 4 | | IF | ID | EX | MEM | WB | | |
| 3. lw t1, 0(t0) | | | IF | ID | EX | MEM | WB | |
| 4. add t2, t1, x0 | | | | IF | ID | EX | MEM | WB |

4.4

Say you are the compiler and can re-order instructions to minimize data hazards while guaranteeing the same output. How can you fix the code above?

Detecting Data Hazards

Say we have the rs1, rs2, RegWEn, and rd signals for two instructions (instruction n and instruction n+1) and we wish to determine if a data hazard exists across the instructions. We can simply check to see if the rd for instruction n matches either rs1 or rs2 of instruction n+1, indicating that such a hazard exists (think, why does this make sense?).

We could then use our hazard detection to determine which forwarding paths/number of stalls (if any) are necessary to take to ensure proper instruction execution. In pseudo-code, this could look something like the following:

```
if (rs1(n + 1) == rd(n) \mid \mid rs2(n + 1) == rd(n) \&\& RegWen(n) == 1) { forward ALU output of instruction n }
```

Control Hazards

Control hazards are caused by **jump and branch instructions**, because for all jumps and some branches, the next PC is not PC + 4, but the result of the computation completed in the EX stage. We could stall the pipeline for control hazards, but this decreases performance.

4.5 Besides stalling, what can we do to resolve control hazards?

Extra for Experience

4.6 Given the RISC-V code above and a pipelined CPU with no forwarding, how many hazards would there be? What types are each hazard? Consider all possible hazards from all pairs of instructions, and feel free to use any techniques in class (i.e. branch prediction) to limit the number of stalls.

How many stalls would there need to be in order to fix the data hazard(s)? What about the control hazard(s)?

| Instruction | C1 | C2 | С3 | C4 | C5 | C6 | C7 | C8 | С9 |
|----------------------|----|----|----|-----|-----|-----|-----|-----|----|
| 1. sub t1, s0, s1 | IF | ID | EX | MEM | WB | | | | |
| 2. or s0, t0, t1 | | IF | ID | EX | MEM | WB | | | |
| 3. sw s1, 100(s0) | | | IF | ID | EX | MEM | WB | | |
| 4. bgeu s0, s2, loop | | | | IF | ID | EX | MEM | WB | |
| 5. add t2, x0, x0 | | | | | IF | ID | EX | MEM | WB |

