# User Manual

### Running Model Deplyment

Once you have gone thought the instalation guide for the Model Deployment Program you can run the ESP-IDF 5.0 CMD as shown bellow and run the following comands to make an inference on a hardcoded rest image.

Make sure you are in the model deployment directory

#### cd model\_deployment

Make sure that COMX is the current port that your ESP32 Chip is connected too i.e.  ${\rm COM5}$ 

idf.py set-target esp32

Check if the flash is configured to 4MB by typing


idf.py menuconfig

Then compline and run by doing the following.

idf.py build


idf.py -p COMX flash

idf.py -p COMX monitor



## How to Change The Sample Image

You can generate new example images that you can classify directly on the chip by doing the following. Run the notebook found in model\_deployment and scroll to the bottom of the notbook under the heading "Testing". There is some code there you can run to turn an image at the index you desire into a C++ array which you can copy and past it as the example image in the model\_deployment program.





This is how the output would look like from the google notebook. The C++ array generated are the numbers you see above the image.

To save this as an example image that the chip can classify you would take this C++ array and paste it here so that example\_element[] is now equal to the new array you generated.


### How to Run The Webserver

- First make sure that your ESP-32 chip is mounted onto the microscope and that it is connected to your local computer through a USB cable.
- To run the camera-web server onto the chip you would need to download the Arduino IDE to compile and flash the web server code onto the chip. You can install Arduino IDE from https://www.arduino.cc/en/software
- Go to file, preferences, and add the additional board manager url https://raw.githubusercontent.com/espressif/arduino-esp32/ghpages/package\_esp32\_index.json





• To download the camera web server code you can clone our repository to access it https://github.com/rdgbrian/cap-2-project-algea-detection, and open the webserver code in your IDE. Or alternatively you can access it though the IDE. You can access it though the IDE by setting the current board to be the ESP32 Dev Module. Then selecting file->examples->ESP32->Camera->CameraWebServer




Once selected be sure to use the AI Thinker model and not the ESP 32 Eye cam model:

```
// select camera model
// select camera model
// #define CAMERA_MODEL_WROVER_KIT // Has PSRAM
//#define CAMERA_MODEL_ESP_EYE // Has PSRAM
//#define CAMERA_MODEL_ESP_S32S3_EYE // Has PSRAM
//#define CAMERA_MODEL_ESP32S3_EYE // Has PSRAM
//#define CAMERA_MODEL_M5STACK_PSRAM // Has PSRAM
//#define CAMERA_MODEL_M5STACK_V2_PSRAM // M5Camera version B Has PSRAM
//#define CAMERA_MODEL_M5STACK_WIDE // Has PSRAM
//#define CAMERA_MODEL_M5STACK_WIDE // Has PSRAM
//#define CAMERA_MODEL_M5STACK_UNITCAM // No PSRAM
//#define CAMERA_MODEL_AI_THINKER // Has PSRAM
//#define CAMERA_MODEL_AI_THINKER // Has PSRAM
//#define CAMERA_MODEL_XIAO_ESP32S3 // Has PSRAM
// ** Espressif Internal Boards **
//#define CAMERA_MODEL_ESP32S_CAM_BOARD
//#define CAMERA_MODEL_ESP32S_CAM_BOARD
//#define CAMERA_MODEL_ESP32S3_CAM_LCD
//#define CAMERA_MODEL_ESP32S3_CAM_LCD
//#define CAMERA_MODEL_DFROBOT_FireBeetle2_ESP32S3 // Has PSRAM
//#define CAMERA_MODEL_DFROBOT_FireBeetle2_ESP32S3 // Has PSRAM
```

You will then need to fill out the required credentials which will be the internet connection name under ssid and password under the password

• Once you are ready to run your program. Check if the correct bord and port (USB connection) is selected by pressing the button that has the usb symbol in the top middle of your screen.



• Then compline and flash your code onto the chip. Open the serial monitor

in the IDE to see the input from the chip. This input will provide a link to access the live camera input. Copy and paste this link onto your browser to interact and view the live video.