
# AE 242 Aerospace Measurements Laboratory

Kalman filter is an state estimator. It fuses states from dynamical model and measurement to give best estimates. It is applicable to linear system.

First major application was in Apollo space navigation. It is used in almost all the systems e.g. aerospace, powerplant, electronics, automobile, marine etc.

Other popular extension of Kalman filter for nonlinear systems are Extended Kalman Filter (EKF), Unscented Kalman Filter (UKF) etc,



Using system model states can be predicted. It will have uncertainty due to modeling errors.

Measurement can be used to compare with estimated state and weighted difference is added to update the predicted state

#### **Predict**

Propagate state

Propagate error covariance

### Measurement update

Compute Kalman gain

Update state with measurement

Update error covariance



Let us take a linear discrete system

$$x_{k+1} = Ax_k + Bu_k + w_k$$

Using above equation state  $\mathcal{X}_{k+1}$  can be obtained at k+1 instant from the state and input at k instant.  $\mathcal{W}_k$  is process noise. A is transition matrix and B is control matrix.

$$y_k = Cx_k + z_k$$

 $\mathcal{Y}_k$  is measurement at k instant. C is output matrix and  $\mathcal{Z}_k$  is measurement noise.

$$P_{k} = AP_{k-1}A^{T} + S_{w}$$

Error covariance prediction (difference of estimated and updated states)

Based on the error covariance, Kalman gain is calulated

$$K_{k} = AP_{k}C^{T}(CP_{k}C^{T} + S_{z})^{-1}$$

Error between measurement and predicted state also called

as innovation 
$$innov = y_{k+1} - C x_k$$

Update error covariance

$$P_{k+1} = AP_kA^T + S_w - AP_kC^TS_z^{-1}CP_kA^T$$

A vehicle moving in a straight line. Input is commanded acceleration. We can obtain velocity and position by integration. *T* is integration time step. Velocity:

$$v_{k+1} = v_k + Tu_k$$
 Ideal – no noise

$$v_{k+1} = v_k + Tu_k + v_k$$
 Real - noise

 $v_k^{\sim}$  noise in velocity

Position:

$$p_{k+1} = p_k + Tv_k + \frac{1}{2}T^2u_k + p_k^{\tilde{}}$$

 $p_k^{\tilde{}}$  noise in position

Let the state vector be position and velocity


$$x_k = \begin{bmatrix} p_k \\ v_k \end{bmatrix}$$

System equation can be written as

$$x_{k+1} = \begin{bmatrix} p_{k+1} \\ v_{k+1} \end{bmatrix} = \begin{bmatrix} 1 & T \\ 0 & 1 \end{bmatrix} x_k + \begin{bmatrix} T^2/2 \\ T \end{bmatrix} u_k + w_k$$

Measurement equation


$$y_k = \begin{bmatrix} 1 & 0 \end{bmatrix} x_k + z_k$$
 Position measurement with noise




Don Simon, Kalman Filtering, June 2001, Embedded Systems Programming

U= 1 ft / square (sec)


Process model error: 0.2 feet/square(sec)



Process model error: 0.2 feet/square(sec)



Process model error: 0.2 feet/square(sec)



Process model error: 0.2 feet/square(sec)

## The Equations of Motion for INS

$$\dot{u} = a_x - qw + rv - g\sin\theta$$

$$\dot{v} = a_y - ru + pw + g\cos\theta\sin\phi$$

$$\dot{w} = a_z - pv + qu + g\cos\theta\cos\phi$$

$$\dot{\phi} = p + \tan\theta(q\sin\phi + r\cos\phi)$$

$$\dot{\theta} = q\cos\phi - r\sin\phi$$

$$\dot{\psi} = \sec\theta(q\sin\phi + r\cos\phi)$$


# The Navigation equations

$$[v]_I = R_B^I [v]_B$$


 $\dot{x} = u\cos\theta\cos\psi + v(\sin\varphi\sin\theta\cos\psi - \cos\phi\sin\psi) + w(\cos\phi\sin\theta\cos\psi + \sin\varphi\sin\psi)$ 

 $\dot{y} = u\cos\theta\sin\psi + v(\sin\theta\sin\phi\sin\psi + \cos\phi\cos\psi) + w(\cos\phi\sin\theta\sin\psi - \sin\phi\cos\psi)$ 

 $\dot{z} = -u\sin\theta + v\sin\phi\cos\theta + w\cos\phi\cos\theta$ 




Two thermometers are used for measuring temperature. 200 samples are recorded when temperature input is 5 units. From the above two observations, what can be deduced about thermometers?




Bias and drift can be estimated by suitable curve fitting (static case).

Bias and drift (time varying) can be estimated by using estimation methods like Kalman filter (Dynamic case).

### Common error models - deterministic



### **Common error models**



- + determin sitic errors
- + stocahstic errors




Fig. 6.21 Block diagram of aided IN system with Kalman filter.




Fig. 6.20 Aided INS with simple positional reset.

# **Aiding**

#### Position based:

GPS / NaVIC etc (Outdoor): Limited to satellite visibility; prone to spoofing.

Range measurement (indoor): UWB sensors; TOF; ultrasonic;

Vision: Processing camera pose and image of known object (position)

#### **Velocity:**

Odometry – Independent measurement of speed / velocity. Wheel speed; Optic flow;

# Summary of the lectures

- What is measurement, instrumentation?
- Functional elements of a measurement system
- Standards
- Measurement of resistance
- Wheatstone bridge : Bending, tension, temperature compensation
- Dynamics characteristics
- Analog to digital conversion
- Operational amplifier

# Summary of the lectures

- Digital electronics: Combinational and sequential
- GPS and its applications
- Inertial sensors
- > Attitude measurement
- Air Data system
- > Temperature measurement
- Kalman filter