

Toposolid Grading Script

- Open Revit first. Make sure your project has an existing Toposolid and a building Floor.
- Launch Rhino.Inside from the Revit ribbon (Rhino.Inside tab → Start).
- Wait for Grasshopper to fully load before opening the script.
- Open the script from the Standards drive path shown below.

Follow these steps in order:

- 1 Open Rhino.Inside**
Revit ribbon → Rhino.Inside tab → Start. Wait for Grasshopper to load.
- 2 Open the script**
In Grasshopper: File → Open → navigate to the path below.
- 3 Set Toposolid**
Right-click the Toposolid input → Set one Toposolid → pick in Revit.
- 4 Set Building Floor**
Right-click the Floor input → Set one or multiple Floors → pick in Revit.
- 5 Adjust sliders**
Topo Control Points (default 25), Extent in Feet (default 10), Contours (default 1ft).
- 6 Check preview**
Review the mesh in the Rhino/Revit viewport. Adjust sliders if needed.
- 7 Bake to Revit**
Toggle the red switch → TRUE to bake. Switch back to FALSE immediately after.

Script location — Standards (S:) drive

```
S:\Toolbox\Drawing Standards\_Emerging Tech CoLab\Automation & Scripting  
\_Script Library\Generative\ Toposolid - V2-00.gh
```

! Do not leave the toggle on **TRUE** — this will create duplicate Toposolid elements in Revit.
Undo immediately with Ctrl+Z if this happens.

i Remove Subregion boundaries from the Toposolid before running.
If the surface looks faceted, increase Topo Control Points (try 35 or 50).