

PC StartUp Manual

Release date: Feb, 2020


©2020 M3 MOBILE Co., Ltd. All Rights Reserved.

CHAPTER. STARTUP FOR PC	3
1. StartUp Admin Login	3
2. PROFILE	4
3. Settings	
3-1. Wi-Fi Access Point	5
3-2. Wi-Fi Preference	
3-3. Wi-Fi Remove	
3-4. APN	7
3-5. File Download	8
3-6. Install APK	
3-7. Time Setting	9
3-8. Start Application	9
3-9. ETC	
4. Export Barcodes	11
Release History	12
SERVICES	13

Chapter. StartUp For PC

Supported Restriction
StartUp (Android) Application Version Higher than 3.1.0


1. StartUp Admin Login



■ Login

- ✓ Input the Password to enter Admin Mode
- ✓ Default Password is 'mobile'.

2. PROFILE



Making Profile

- ✓ Here user can edit setting profiles.
- ✓ Add New Profile: Profiles can be added.
- ✓ Import Profile: Select any 'StartUp.Json' File using File Dialog by click this menu

■ Profile Management

- ✓ Profile can be managed selecting any profile.
- ✓ Add Settings: Add and manage settings on selected profile.
- ✓ Export Barcodes: The profile can be made to barcodes.
- ✓ Remove: You can delete the selected profile.
- ✓ Rename: Change the profile name
- ✓ Duplicate: Copy and paste the profile.

■ Others

- ✓ Open StartUp Folder: Open the folder where the JsonFiles are saved.
- ✓ Refresh: Update the Json Profile in the StartUp Folder.

- ✓ Change Password: Change the Admin Password. Password is saved in StartUP_Setting.json file in StartUp Folder.
- ✓ Log-Out: Return to the state where you need to enter the Admin Password.


3. Settings



Add Settings

- ✓ Wi-Fi Access Point: Setting Wireless LAN access point
- ✓ Wi-Fi Preference: Setting Wireless LAN details
- ✓ Wi-Fi Remove: Wi-Fi settings can be removed.
- ✓ APN: Setting APN for network
- ✓ File Download: It will download any files on internet
- ✓ Install APK: APK files can be installed in this setting
- ✓ Date and Time: Can set the date, Time and the NTP server.
- ✓ Start Application: Application to run when the terminal starts.
- ✓ ETC: Bluetooth, Display, Volume, Launcher, OTA

3-1. Wi-Fi Access Point



■ Wi-Fi Access Point Settings


- ✓ Wi-Fi Auto on: Wi-Fi AutoOn when reboot.
- ✓ Wi-Fi Settings enable: Allow to the provision Wi-Fi setting can access an AP. 'Wi-Fi AutoOn on' should be enabled.
- ✓ SSID: Access to SSID(Be careful of Upper/Lower case letter.)
- ✓ Password: Input PW for the SSID.
- ✓ Static IP Setting: Enable Static IP setting.
- ✓ Static IP: Input Static IP address
- ✓ Subnet Mask: Input Subnet Mask.(0~32)

Notation	Netmask
0	0.0.0.0
8	255.0.0.0
16	255.255.0.0
24	255.255.255.0
25	255.255.255.128
32	255.255.255

✓ Gateway: Input Gateway address.

Domain Name Server: Input DNS address.


3-2. Wi-Fi Preference



■ Wi-Fi Preference

✓ Set detailed settings to be common


3-3. Wi-Fi Remove



■ Wi-Fi Remove

- Delete the Wifi information set in the device.
- ✓ Remove All: Delete All Wifi Setting
- ✓ SSID: Delete the specified SSID setting


3-4. APN



APN Settings

- ✓ Set the value according to the network environment you want to set.
- ✓ Do not leave the Name, APN, MCC, and MNC fields blank.


3-5. File Download



■ File Download

- ✓ Enable File Download: Check to use download function.
- ✓ URL : Input correct URL want to download.
- Destination : Select the destination folder on your device.


3-6. Install APK



■ Install APK

- ✓ Enable File Download: Check to use download function.
- ✓ URL : Input correct URL want to download.
- ✓ Destination : Select the destination folder on your device.


3-7. Time Setting



■ Date and Time

- ✓ NTP URL Specifies the URL of the NTP server
- ✓ Date and TimeSet to the specified date and time.(Applies only once at next boot)


3-8. Start Application



Start Application

- ✓ Setting application that run on boot
- Insert Package name to launch the application

3-9. ETC



Display Settings

- ✓ Auto Brightness: Brightness's adjusted by light condition automatically.
- ✓ Brightness Step: Adjust Brightness.
- ✓ Display Auto Rotate: Automatically display rotated between portrait and landscape.
- ✓ ScreenLock Disable : Select to disable ScreenLock
- ✓ Sleep: Set the time for the device to enter sleep.

Volume Settings


- ✓ Volume Settings Enable: Allow to Volume Control when reboot.
- ✓ Vibrator Enable: Vibrator enabled when reboot.
- ✓ Media Volume: Media Volume can be set.
- ✓ Ringtone Volume: Ringtone Volume can be set.
- ✓ Alarm Volume: Alarm Volume can be set.

Location Setting

- ✓ Specifies the Location mode
- Language Settings : Select the language to use on your device
- NFC Settings : Select whether NFC and NFC beam are to be used.


- OTA Settings : Specify the URL to use when running OTA updates remotely
- Airplane Mode :Turn on/off the airplane mode
- Bluetooth Auto on: Bluetooth Auto On when reboot.
- Unknown source : Allow installation of apps from sources other than the Play Store

4. Export Barcodes



■ Export Barcodes

- ✓ Barcodes: Can be read on PDA for StartUp
- ✓ Memo: Notes to leave when saving as PDF
- ✓ PDF: save as PDF file



Release History

Version 1.0.0 Date 2020-01-31

- First Release.

Services

If you experience any trouble while using our product, you can visit **M3 Service center** or send enquires to our **online support web page** (http://itc.m3mobile.net), we will do our best to solve your trouble as soon as we can.

M3 FAQ document can help you with troubleshooting.

For any enquires about business program, please contact program provider for faster service.

Contact details

Headquarter

4F, Namjeon bldg., 44, Guuigangbyeon-ro, Gwangjin-gu, Seoul, Korea, 05116 Tel: +82 2 574 0037 Fax: +82 2 558 1253

www.m3mobile.net, sales@m3mobile.co.kr

Factory / Service Center

Chun-ui Techno Park 201-610, 202, Chunui-Dong, WonMi-Gu, Buchoen, Gyeonggi-Do, 420-857, Korea

Tel: +82 32 623 0030, Fax: +82 32 623 0035

Online Support Web page

http://itc.m3mobile.net