REG		0	1	2	3	4	5	6	7	8	9	Α	В	С	D	Е	F	note
Driver config	0x00 W/R	Directio n	8Bits PWM duty	16Bits PWM duty-L	16Bits PWM duty-H	PWM Freq-L	PWM Freq-H											Direction: 0, Stop(default); 1, Forward; 2, Rverse 8Bits PWM duty: 0~255 16Bits PWM duty: 0~65535 PWM Freq: 100~10000Hz(default 1000Hz)
VIN ADC 8bits	0x10	ADC Value																<b>Vaule</b> : 0~255
VIN ADC	0x20		ADC															
12bits	R		Value-H															<b>Vaule</b> : 0~4095
Firmware Version	0xF0		, alas II													FW Version		Value: firmware version
I2C Addr	0xF0 R																I2C Addr	Value: I2C Address
I2C ADDR S	W	0	1	2	3													
0x20		OFF	OFF	OFF	OFF													
0x21		ON	OFF	OFF	OFF													
0x22		OFF	ON	OFF	OFF													
0x23		ON	ON	OFF	OFF													
0x24		OFF	OFF	ON	OFF													
0x25		ON	OFF	ON	OFF													
0x26		OFF	ON	ON	OFF													
0x27		ON	ON	ON	OFF													
0x28		OFF	OFF	OFF	ON													
0x29		ON	OFF	OFF	ON													
0x2A 0x2B		OFF ON	ON ON	OFF OFF	ON ON													
0x2B 0x2C		OFF	OFF	ON	ON													
0x2C 0x2D		ON	OFF	ON	ON													
0x2E		OFF	ON	ON	ON													
0x2F		ON	ON	ON	ON													
UAL!					CIV													