Computer Architecture

Control Unit Operation

Md. Biplob Hosen Lecturer, IIT-JU

Reference Books

- Computer Organization and Architecture: Designing for Performance- William Stallings (8th Edition) (CH-15)
 - Any later edition is fine

Functional Requirements of Control Unit

- Those functions that the control unit must perform.
- Control unit characterization:
 - 1. Define the basic elements of the processor.
 - 2. Describe the micro-operations that the processor performs.
 - 3. Determine the functions that the control unit must perform to cause the micro-operations to be performed.

1. Basic functional elements of the processor:

- ALU: Functional essence of the computer.
- Registers: Internal storage of processor. Also used for PSW.
- Internal data paths: Move data between registers and ALU.
- External data paths: Registers to memory and I/O module.
- Control unit: Causes operations to happen within processor.


2. Micro-operations categories:

- Data transfer from one register to another.
- Data transfer from a register to an external interface.
- Data transfer from an external interface to a register.
- An arithmetic or logic operation using registers for I/O.

- 3. The control unit performs two basic tasks using control signals:
 - Sequencing: Sequencing micro-operations based on the program.
 - Execution: Causes micro-operations to be performed.

Control Signals:

- For control unit to perform tasks, it must have inputs that allow to determine the state of the system and outputs that allow to control the behavior of the system.
- These are the external specifications of the control unit.
- Internally, the control unit must have the logic required to perform its sequencing and execution functions.



Block Diagram of the Control Unit

- This figure is a general model of control unit, showing all of its inputs and outputs.
- Inputs are:
 - Clock: For keeping time. One μ -operation per clock (Cycle time).
 - IR: Opcode & addressing mode of current instruction.
 - Flags: Status of processor & outcome of previous ALU operation.
 - Control signals from control bus.


- Outputs are:
 - Control signals within the processor: Two types:
 - Those cause data to be moved from one register to another.
 - Those activate specific ALU functions.
 - Control signals to control bus: Two types:
 - Control signals to memory.
 - Control signals to I/O modules.
- So, three types of control signals are used:
 - Those activate an ALU function.
 - Those activate data-path.
 - Those are signals on the external system bus or other interfaces.
- All the signals are applied directly as binary inputs to individual logic gates.

Consider again the fetch cycle Example:

- The control unit (CU) keeps track of where it is in the instruction cycle.
- Lets consider a given point, when CU knows that fetch cycle is to be performed next.
- 1st step: Transfer contents of PC to MAR. CU does this by activating the control signal that opens gates between the bits of the PC and bits of the MAR.
- 2nd step: Read word from memory into MBR & increment PC. CU does this by sending following control signals simultaneously:
 - A control signal that opens gates, allowing the content of MAR onto the address bus.
 - A memory read control signal on the control bus.
 - A control signal that opens gates, allowing the contents of the data bus to be stored in MBR.
 - Control signals to logic that add 1 to the contents of PC and store result back to the PC.
- 3rd step: Transfer contents between MBR & IR. CU sends a control signal that opens gate between MBR & IR.

Internal Processor Organization

- Following figure illustrates the structure of a CPU with internal-bus.
- A single internal bus connects the ALU & all processor registers.
- Gates & control signals are provided for movement of data onto & off the bus from each register.
- Additional control signals control data transfer to & from the system bus & the operation of the ALU.
- Two new registers Y & Z are added to the organization.
- These are needed for the prope operation of the ALU.
- Y provides temporary storage for inputs.
- Z provide temporary storage for outputs.



- With this arrangement, an operation to add a value from memory to the AC would have the following steps:
 - T1: MAR \leftarrow (IR (Address))
 - T2: MBR ← Memory
 - T3: Y \leftarrow (MBR)
 - T4: Z \leftarrow (AC) + (Y)
 - T5: AC \leftarrow (Z)

Implementation of Control Unit

- For the implementation of the control unit, various techniques have been used, which falls under two categories:
- Hardware Implementation: The control unit is essentially a state machine circuit. Its input logic signals are transferred into a set of output logic signals, which are the control signals.

Microprogrammed Implementation:

- An alternative to hardware implementation, in which the logic of the control unit is specified by a microprogram.
- A microprogram consists of a sequence of instructions in a microprogramming language.
- That are very simple instructions that specify microoperations.
- A microproammed control unit is capable:
 - Sequencing through micro-instructions.
 - Generating control signals to execute each instructions.

Practice Problems

• Problems: 15.1, 15.2, 15.3, 15.4, 15.5

Thank you!