配置树莓派 wifi 热点

git clone https://gitee.com/mrobotit/mrobot_book.git cd mrobot_book/create_ap/ sudo apt install make ubuntu@ubuntu:~/robot_book/create_ap\$ sudo apt install make Reading package lists... Done Building dependency tree Reading state information... Done make is already the newest version (4.1-9.1ubuntu1). make set to manually installed. \emptyset upgraded, \emptyset newly installed, \emptyset to remove and 155 not upgraded. sudo make install ubuntu@ubuntu:~/robot_book/create_ap\$ sudo make install install -Dm755 create_ap /usr/bin/create_ap install -Dm644 create_ap.conf /etc/create_ap.conf ! -d /lib/systemd/system] || install -Dm644 create_ap.service /usr/lib/systemd/system/create_ap.service [!-e/sbin/openrc-run] || install-Dm755 create_ap.openrc/etc/init.d/create_ap install -Dm644 bash_completion /usr/share/bash-completion/completions/create_ap install -Dm644 README.md /usr/share/doc/create_ap/README.md sudo apt install network-manager

sudo service network-manager start
sudo apt install util-linux procps hostapd iproute2 iw haveged dnsmasq
sudo create ap wlan0 eth0 mrobotit 12345678

```
ubuntu@ubuntu:~/robot_book/create_ap$ sudo create_ap wlan0 eth0 mrobotit 12345678
WARN: brmfmac driver doesn't work properly with virtual interfaces and
    it can cause kernel panic. For this reason we disallow virtual
    interfaces for your adapter.
    For more info: https://github.com/oblique/create_ap/issues/203
WARN: Your adapter does not fully support AP virtual interface, enabling --no-virt
Config dir: /tmp/create_ap.wlan0.conf.J7AxZqBA
PID: 4488
Network Manager found, set wlan0 as unmanaged device... client_loop: send disconnect: Broken pipe
```

热点开机自启

cd /etc/init.d

sudo touch wifi_start.sh

sudo vim wifi start.sh

敲入下面内容

#!/bin/bash

BEGIN INIT INFO

Provides: svnd.sh

Required-start: \$local_fs \$remote_fs \$network \$syslog # Required-Stop: \$local_fs \$remote_fs \$network \$syslog

Default-Start: 2 3 4 5 # Default-Stop: 0 1 6

Short-Description: starts the wifi daemon

Description: starts svnd.sh using start-stop-daemon

END INIT INFO

sudo create_ap wlan0 eth0 mrobotit 12345678

ubuntu@ubuntu:~\$ cat /etc/init.d/wifi_start.sh

#!/bin/bash

BEGIN INIT INFO

Provides: svnd.sh

Required-start: \$local_fs \$remote_fs \$network \$syslog
Required-Stop: \$local_fs \$remote_fs \$network \$syslog

Default-Start: 2 3 4 5 # Default-Stop: 0 1 6

Short-Description: starts the wifi daemon

Description: starts svnd.sh using start-stop-daemon

END INIT INFO

sudo create_ap wlan0 eth0 mrobotit 12345678

sudo chmod 775 wifi_start.sh sudo update-rc.d wifi_start.sh defaults 95