






Raspberry Pi






UI switches


3v3 +5V




Open collector CLK/DAT




IEC connectors




Disk head movements




OLED



Levelshifter



Reset



Signalling LEDs

	Browse mode	Emulation mode
SW1SEL	Select / Start emulation	-
SW2PRV	Previous file	Previous disk in list
SW3NXT	Next file	Next disk in list
SW4ESC	Exit folder	Exit emulation
SW5INS	Insert disk to list	-

SW1 and SW4 as in V1.26 (earlier: swapped)

L0POW (RED) R0 changed from 10k to 3k3
L1ACT (GRN) R1 changed from 1k to 47k
L4DAT (BLU) R4 changed from 4k7 to 2k2