Shamazon Warehouse Robot: UML Class Diagram

User Interface

- + delivery_floor: int
- + delivery_location :string
- + setDeliveryLocation(string): void
- + setDeliveryFloor(int): void



Navigation

- + nh: ROS::NodeHandle
- goal status: bool
- _pickup_goal: double[]
- delivery goal: double []
- _move_base_client: move_base_msgs::MoveBaseAction
- _robot_pose: nav_msgs:: Odometry Message
- + poseCallback(const nav msgs::Odometry::ConstPtr &msg): void
- + sendGoalsToActionServer(float, float, float): void
- + activateConveyor(void): bool
- + activaeRobotConveyor(void): bool
- + updateGlobalMap(int): void



Elevator

- elevator floor: int
- elevator status: bool
- + getElevatorFloor(void): int
- + moveElevator(int): bool