

Event Variables

Index

Part I	Introduction	4
Part II	History	4
Part III	Event Variables	4
1	Examples of Usage.....	4
	Send E-mail	4
	Send Message to Operator	5
	Create Bookmark	6
Part IV	Events	6
1	Communication events.....	7
2	I/O Input event.....	7
3	Device Video Loss.....	7
4	Device Disk Failure.....	7
5	Device Intercom Button.....	8
6	Recording Failure.....	8
7	Motion Detection.....	8
8	Audio Level Detection.....	8
9	Global Event.....	9
10	Manual Event.....	9
11	Scheduled Event.....	9
12	Analytics.....	9
13	LPR Event.....	10
14	Failover.....	10
15	Timer.....	10
	Index	0

1 Introduction



This document describes text variables that can be used within event actions

2 History

Date	Revision	Comments
2018-Oct-26	Éric Fleming Bonilha	First version

3 Event Variables

Digifort allows the use of dynamic values from event variables within event actions.

The value of Event Variables can be accessible by referencing the variable name by using a special identifiers around the variable name: `$(VARIABLE_NAME)`

Each event from Digifort introduces different variables whose values can be used in event actions.

The following event actions support the use of variables:

- Send Email
- Send Message to the Operator
- Send HTTP Request
- Create Bookmark

3.1 Examples of Usage

3.1.1 Send E-mail

In the following example, an e-mail will be sent with specific data from an LPR event which includes the License Plate number and the Driver Name in a case that the recognized plate is flagged robbery.

Event action (Send e-mail)

E-Mail

Configure e-mail sending

E-mail group:
Emails

Message:
Suspect of robbery
Event Name: \${EVENT_NAME},
Camera: \${CAMERA_NAME},
License Plate: \${LICENSE_PLATE},
Driver Name: \${PLATE_OWNER},
Details: \${PLATE_REMARKS},
Lists: \${PLATE_LISTS}

☒ Include camera image
Number of images (1 image per second prior to the event)
1

Available objects

- Camera
- Analytics configuration

Selected objects

- Camera
40

SMS:
☒ Use default SMS message
☐ Use custom SMS message

☐ Include link for event playback
☐ Use this server record
☐ Auto Login

Server IP: Port: 8600 User: Password:

OK Cancel

3.1.2 Send Message to Operator

Event action (Send message)

Message

Configure operator message

Message:
Suspect of robbery
Event Name: \${EVENT_NAME}
Camera: \${CAMERA_NAME}
License Plate: \${LICENSE_PLATE}
Name: \${PLATE_OWNER}
Details: \${PLATE_REMARKS}
Lists: \${PLATE_LISTS}

OK Cancel

3.1.3 Create Bookmark

In this example, we can register the license plate number as a bookmark

Event action (Create bookmark) ✕

Bookmark

 Configure bookmark creation options

Title Color  Red ▾

Hours Minutes Seconds

Create a bookmark with start date/time of 0 seconds prior to the time of the event until the time of the event

▼  Camera

.....  40

4 Events

Each event can have a different set of variables, the following section describes the variables of each event.

4.1 Communication events

Variable Name	Description			
DEVICE_TYPE	Type of device that triggered the event <table><tr><th>Device Type</th></tr><tr><td>CAMERA</td></tr><tr><td>IO_DEVICE</td></tr></table>	Device Type	CAMERA	IO_DEVICE
Device Type				
CAMERA				
IO_DEVICE				
DEVICE_NAME	Name of the device that triggered the event			
EVENT_TYPE	<table><tr><th>Event Type</th></tr><tr><td>COMMUNICATION_FAILURE</td></tr><tr><td>COMMUNICATION_RESTORED</td></tr></table>	Event Type	COMMUNICATION_FAILURE	COMMUNICATION_RESTORED
Event Type				
COMMUNICATION_FAILURE				
COMMUNICATION_RESTORED				
INACTIVITY_TIME	Number of seconds that the device is / was offline			

4.2 I/O Input event

Variable Name	Description			
DEVICE_TYPE	Type of device that triggered the event <table><tr><th>Device Type</th></tr><tr><td>CAMERA</td></tr><tr><td>IO_DEVICE</td></tr></table>	Device Type	CAMERA	IO_DEVICE
Device Type				
CAMERA				
IO_DEVICE				
DEVICE_NAME	Name of the device that triggered the event			
EVENT_TYPE	Identifies the type of event, value is always ALARM_INPUT			
EVENT_NAME	Name of the event			

4.3 Device Video Loss

Variable Name	Description		
DEVICE_TYPE	Type of device that triggered the event <table><tr><th>Device Type</th></tr><tr><td>CAMERA</td></tr></table>	Device Type	CAMERA
Device Type			
CAMERA			
DEVICE_NAME	Name of the device that triggered the event		
EVENT_TYPE	Identifies the type of event, value is always DEVICE_VIDEO_LOSS		

4.4 Device Disk Failure

Variable Name	Description		
DEVICE_TYPE	Type of device that triggered the event <table><tr><th>Device Type</th></tr><tr><td>CAMERA</td></tr></table>	Device Type	CAMERA
Device Type			
CAMERA			

DEVICE_NAME	Name of the device that triggered the event
EVENT_TYPE	Identifies the type of event, value is always DEVICE_DISK_FAILURE

4.5 Device Intercom Button

Variable Name	Description
DEVICE_TYPE	Type of device that triggered the event Device Type CAMERA
DEVICE_NAME	Name of the device that triggered the event
EVENT TYPE	Identifies the type of event, value is always DEVICE INTERCOM BUTTON

4.6 Recording Failure

Variable Name	Description		
DEVICE_TYPE	Type of device that triggered the event <table><tr><th>Device Type</th></tr><tr><td>CAMERA</td></tr></table>	Device Type	CAMERA
Device Type			
CAMERA			
DEVICE_NAME	Name of the device that triggered the event		
EVENT TYPE	Identifies the type of event, value is always RECORDING_FAILURE		

4.7 Motion Detection

Variable Name	Description		
DEVICE_TYPE	Type of device that triggered the event <table><tr><th>Device Type</th></tr><tr><td>CAMERA</td></tr></table>	Device Type	CAMERA
Device Type			
CAMERA			
DEVICE_NAME	Name of the device that triggered the event		
EVENT_TYPE	Identifies the type of event, value is always MOTION		

4.8 Audio Level Detection

Variable Name	Description			
DEVICE_TYPE	Type of device that triggered the event <table><tr><th>Device Type</th></tr><tr><td>CAMERA</td></tr></table>	Device Type	CAMERA	
Device Type				
CAMERA				
DEVICE_NAME	Name of the device that triggered the event			
EVENT_TYPE	<table><tr><th>Event Type</th></tr><tr><td>AUDIO_LEVEL_LOW</td></tr><tr><td>AUDIO_LEVEL_HIGH</td></tr></table>	Event Type	AUDIO_LEVEL_LOW	AUDIO_LEVEL_HIGH
Event Type				
AUDIO_LEVEL_LOW				
AUDIO_LEVEL_HIGH				

4.9 Global Event

Variable Name	Description
EVENT_TYPE	Identifies the type of event, value is always GLOBAL
EVENT_NAME	Name of the Global event
USERNAME	User account that triggered the event
USER_IP	IP of the user that triggered the event
MESSAGE	Event message

4.10 Manual Event

Variable Name	Description		
DEVICE_TYPE	Type of device that triggered the event <table><tr><th>Device Type</th></tr><tr><td>CAMERA</td></tr></table>	Device Type	CAMERA
Device Type			
CAMERA			
DEVICE_NAME	Name of the device that triggered the event		
EVENT_TYPE	Identifies the type of event, value is always MANUAL		
EVENT_NAME	Name of the Manual event		
USERNAME	User account that triggered the event		
USER_IP	IP of the user that triggered the event		

4.11 Scheduled Event

Variable Name	Description
EVENT_TYPE	Identifies the type of event, value is always SCHEDULED
EVENT_NAME	Name of the Scheduled event

4.12 Analytics

Variable Name	Description																		
EVENT_TYPE	<table><tr><th>Event Type</th></tr><tr><td>ANALYTICS_PRESENCE</td></tr><tr><td>ANALYTICS_ENTER</td></tr><tr><td>ANALYTICS_EXIT</td></tr><tr><td>ANALYTICS_APPEAR</td></tr><tr><td>ANALYTICS_DISAPPEAR</td></tr><tr><td>ANALYTICS_STOP</td></tr><tr><td>ANALYTICS_LOITER</td></tr><tr><td>ANALYTICS_DIRECTION</td></tr><tr><td>ANALYTICS_SPEED</td></tr><tr><td>ANALYTICS_TAILGATING</td></tr><tr><td>ANALYTICS_COUNTING_LINE_A</td></tr><tr><td>ANALYTICS_COUNTING_LINE_B</td></tr><tr><td>ANALYTICS_TAMPER</td></tr><tr><td>ANALYTICS_ABANDONED_OBJECT</td></tr><tr><td>ANALYTICS_REMOVED_OBJECT</td></tr><tr><td>ANALYTICS_SMOKE</td></tr><tr><td>ANALYTICS_FIRE</td></tr></table>	Event Type	ANALYTICS_PRESENCE	ANALYTICS_ENTER	ANALYTICS_EXIT	ANALYTICS_APPEAR	ANALYTICS_DISAPPEAR	ANALYTICS_STOP	ANALYTICS_LOITER	ANALYTICS_DIRECTION	ANALYTICS_SPEED	ANALYTICS_TAILGATING	ANALYTICS_COUNTING_LINE_A	ANALYTICS_COUNTING_LINE_B	ANALYTICS_TAMPER	ANALYTICS_ABANDONED_OBJECT	ANALYTICS_REMOVED_OBJECT	ANALYTICS_SMOKE	ANALYTICS_FIRE
Event Type																			
ANALYTICS_PRESENCE																			
ANALYTICS_ENTER																			
ANALYTICS_EXIT																			
ANALYTICS_APPEAR																			
ANALYTICS_DISAPPEAR																			
ANALYTICS_STOP																			
ANALYTICS_LOITER																			
ANALYTICS_DIRECTION																			
ANALYTICS_SPEED																			
ANALYTICS_TAILGATING																			
ANALYTICS_COUNTING_LINE_A																			
ANALYTICS_COUNTING_LINE_B																			
ANALYTICS_TAMPER																			
ANALYTICS_ABANDONED_OBJECT																			
ANALYTICS_REMOVED_OBJECT																			
ANALYTICS_SMOKE																			
ANALYTICS_FIRE																			

	ANALYTICS_FACE_DETECTION
INACTIVITY_TIME	Number of seconds that the device is / was offline

4.13 LPR Event

Variable Name	Description
CAMERA_NAME	Name of the camera that triggered the LPR event (Which camera the plate was recognized)
EVENT_TYPE	Identifies the type of event, value is always LPR_EVENT
EVENT_NAME	Name of the LPR event
CONFIGURATION_NAME	Name of the LPR configuration that detected the plate
LICENSE_PLATE	License plate number
PLATE_COUNTRY	License plate country (If available)
PLATE_OWNER	License plate owner
PLATE_REMARKS	Remarks of the license plate (Registered in admin client)
PLATE_RELIABILITY	Reliability information of each character
PLATE_LISTS	Comma-separated list of lists that the recognized plate belongs to
LPR_MIDDLEWARE_DATA	External data retrieved by the middleware

4.14 Failover

Variable Name	Description			
EVENT_TYPE	<table><tr><th>Event Type</th></tr><tr><td>FAILOVER</td></tr><tr><td>FAILBACK</td></tr></table>	Event Type	FAILOVER	FAILBACK
Event Type				
FAILOVER				
FAILBACK				
MONITOR_NAME	Name of the failover monitor			
SERVER_IP	IP address of the server being monitored			

4.15 Timer

Variable Name	Description
EVENT_TYPE	Identifies the type of event, value is always TIMER
EVENT_NAME	Name of the Timer event